

ALARM LIST

for

MAZATROL T PLUS

Manual No. : H732SA0023E

Before using this machine and equipment, fully understand the contents of this manual to ensure proper operation. Should any questions arise, please ask the nearest Technical/Service Center.

IMPORTANT NOTICE

1. Be sure to observe the safety precautions described in this manual and the contents of the safety plates on the machine and equipment. Failure may cause serious personnel injuries or material damage. Please replace any missing safety plates as soon as possible.
2. No modifications are to be performed that will affect operation safety. If such modifications are required, please contact the nearest Technical/Service Center.
3. For the purpose of explaining the operation of the machine and equipment, some illustrations may not include safety features such as covers, doors, etc. Before operation, make sure all such items are in place.
4. This manual was considered complete and accurate at the time of publication, however, due to our desire to constantly improve the quality and specification of all our products, it is subject to change or modification. If you have any questions, please contact the nearest Technical/Service Center.
5. Always keep this manual near the machinery for immediate use.
6. If a new manual is required, please order from the nearest Technical/Service Center with the manual No. or the machine name, serial No. and manual name.

Issued by *Manual Publication Section, Yamazaki Mazak Corporation, Japan*

09. 1995

CONTENTS

	Page
Preface	1
Explanation of the Alarm	2
Structure of the Alarm List	2
Alarm No. 001-013 (System Error)	4
Alarm No. 014-033 (Drive Error)	5
Alarm No. 120-199 (CNC Machine Control Error)	17
Alarm No. 200-349 (Machine PLC Error)	25
Alarm No. 400-499 (Display Operation Error)	50
Alarm No. 500-599 (I/O Error)	65
Alarm No. 600-699 (MAZATROL Program Error)	84
Alarm No. 700-799 (EIA/ISO Program Error)	97
Alarm No. 800-899 (MAZATROL Program Error)	113
Alarm No. 900-999 (EIA/ISO Program Error)	127