

INSTRUCTION MANUAL

V-650 **(FANUC 0i-MC)**

LEADERWAY MACHINERY CO., LTD.,

CONTENTS

PREFACE	I
BRIEF INTRDOCTION	II
1 SAFETY PRECAUTIONS	
1-1 SAFETY PRECAUTIONS	1-1
1-2 GENERAL SAFETY INSTRUCTIONS	1-2
2 MACHINE VIEWING	
2-1 BASIC INTRODUCTION	2-1
2-2 MACHINE OUTLINE DRAWING	2-2
3 SPECIFICATION OF MACHINE	
3-1 MACHINE SPECIFICATION	3-1
3-2 MAIN COMPONENTS SPECIFICATION	3-2
3-3 TOOL SPECIFICATION	3-5
3-4 CHIP CONVEYOR	3-6
4 PREPARATION AND TRANSPORTATION	
4-1 ENVIRONMENTAL REQUIREMENT	4-1
4-2 POWER SUPPLY	4-1
4-3 TRANSPORTATION	4-2
4-4 INSTALLATION AND POWER ON	4-4
4-5 LEVELING	4-6
4-6 SETTING OUT THE GROUND	4-7
5 PNEUMATIC SYSTEM	
5-1 FEATURE OF OUTLINE	5-1
5-2 TECHNICAL DATA	5-2
5-3 THE PRESSURE SETTING METHOD OF F.R.L. UNIT	5-2
5-4 FEATURE OF OUTLINE (REGULATOR)	5-3
5-4 SKETCH OF PNEUMATIC SYSTEM	5-4
6 LUBRICATION SYSTEM	
6-1 TECHNICAL DATA	6-1
6-2 OUTLINE DIMENSION	6-1

6-3 FILL UP LUBRICATION OIL	6-2
-----------------------------------	-----

6-4 THE LOOP SKETCH OF LUBRICATION SYSTEM	6-3
---	-----

7 COOLANT SYSTEM

7-1 OUTLINE DIMENSION OF COOLANT PUMP	7-1
---	-----

7-2 TECHNICAL DATA	7-1
--------------------------	-----

7-3 INSTALLATION AND PIPING NOTES	7-1
---	-----

7-4 TROUBLESHOOTING	7-3
---------------------------	-----

7-5 COMPONENTS OF PUMP	7-3
------------------------------	-----

7-6 THE SKETCH OF COOLANT SYSTEM	7-4
--	-----

8 OIL COOLER (OPTION)

8-1 OUTLINE DIMENSION	8-1
-----------------------------	-----

8-2 REGULAR CHECKING BEFORE OPERATION	8-2
---	-----

8-3 TECHNICAL DATA	8-2
--------------------------	-----

8-4 THE SKETCH OF SPINDLE OIL COOLING RUTE	8-2
--	-----

9 HEAT EXCHANGER

9-1 GENERAL CAUTIONS	9-1
----------------------------	-----

9-2 TECHNICAL DATA	9-1
--------------------------	-----

9-3 OUTLINE DRAWING	9-1
---------------------------	-----

10 MAINTENANCE

10-1 DAILY MAINTENANCE	10-1
------------------------------	------

10-2 WEEKLY MAINTENANCE	10-2
-------------------------------	------

10-3 SEMIANNUAL MAINTENANCE	10-2
-----------------------------------	------

10-4 ANNUAL MAINTENANCE	10-3
-------------------------------	------

10-5 MAINTENANCE FOR ARM TYPE ATC	10-4
---	------

11 OPERATION

11-1 CRT AND INPUT PANEL	11-1
--------------------------------	------

11-2 OPERATION PANEL	11-2
----------------------------	------

11-3 DESCRIPTION OF FUNCTIONAL BUTTONS	11-3
--	------