

Hanger Type Shotblasting Machine

Model "SNM-6CA"

Operation Manual

SINTOKOGIO, LTD.
CHUBU SINTOKOGIO, LTD.
JAPAN

July, 1999

TABLE OF CONTENTS

Inner cover	I
Revision log	II
Foreword	III
Cautions	IV
 CHAPTER 1 INTRODUCTION	
1-1 Operation Manual	
1-2 Ordering Parts	
 CHAPTER 2 SAFETY PRECAUTIONS	
2-1 Warning Labels	
2-2 Safety Devices	
2-3 Safety Instruction	
2-4 List of Warning Labels and Safety Device Layout Drawing	
 CHAPTER 3 GENERAL DESCRIPTION	
3-1 Specifications, overall drawings and electrical drawings	
 CHAPTER 4 CAUTIONS FOR SAFE WORK	
 CHAPTER 5 OPERATION	
5-1 Cautions for Operation	
5-2 Preparation for Operation	
5-3 Operation Procedures	
 CHAPTER 6 WORKPIECE TO BE BLASTED	
 CHAPTER 7 SHOT MATERIAL	
 CHAPTER 8 MAINTENANCE AND INSPECTION	
8-1 Cautions for Maintenance and Inspection	
8-2 Maintenance and Inspection List	
8-3 Lubrication	
 CHAPTER 9 TROUBLESHOOTING	
 CHAPTER 10 PARTS LIST AND STRUCTURAL DRAWINGS	
 CHAPTER 11 MANUALS OF PURCHASED EQUIPMENT	