

Programmable Controllers **C200HX/C200HG/C200HE**

OPERATION MANUAL

OMRON

C200HX/C200HG/C200HE Programmable Controllers

Operation Manual

Revised January 1998

TABLE OF CONTENTS

PRECAUTIONS	xiii
1 Intended Audience	xiv
2 General Precautions	xiv
3 Safety Precautions	xiv
4 Operating Environment Precautions	xiv
5 Application Precautions	xv
6 Conformance to EC Directives	xvi
SECTION 1	
Introduction	1
1-1 Overview	2
1-2 The Origins of PC Logic	2
1-3 PC Terminology	3
1-4 OMRON Product Terminology	4
1-5 Overview of PC Operation	4
1-6 Peripheral Devices	5
1-7 Available Manuals	6
1-8 C200HX/HG/HE Features	7
SECTION 2	
Hardware Considerations	11
2-1 CPU Unit Components	12
2-2 PC Configuration	15
2-3 CPU Unit Capabilities	15
2-4 Memory Cassettes	16
2-5 CPU Unit DIP Switch	19
2-6 Operating without a Backup Battery	20
SECTION 3	
Memory Areas	23
3-1 Introduction	24
3-2 Data Area Structure	25
3-3 IR (Internal Relay) Area	29
3-4 SR (Special Relay) Area	33
3-5 AR (Auxiliary Relay) Area	48
3-6 DM (Data Memory) Area	55
3-7 HR (Holding Relay) Area	68
3-8 TC (Timer/Counter) Area	68
3-9 LR (Link Relay) Area	69
3-10 UM Area	69
3-11 TR (Temporary Relay) Area	70
3-12 EM (Extended Data Memory) Area	70

TABLE OF CONTENTS

SECTION 4

Writing and Inputting the Program	73
4-1 Basic Procedure	74
4-2 Instruction Terminology	74
4-3 Program Capacity	75
4-4 Basic Ladder Diagrams	75
4-5 The Programming Console	88
4-6 Preparation for Operation	91
4-7 Inputting, Modifying, and Checking the Program	104
4-8 Controlling Bit Status	120
4-9 Work Bits (Internal Relays)	122
4-10 Programming Precautions	124
4-11 Program Execution	126
4-12 Special I/O Unit Interface Programs	126
4-13 Analog Timer Unit Programming	130

SECTION 5

Instruction Set	135
5-1 Notation	138
5-2 Instruction Format	138
5-3 Data Areas, Definer Values, and Flags	138
5-4 Differentiated Instructions	140
5-5 Expansion Instructions	141
5-6 Coding Right-hand Instructions	142
5-7 Instruction Set Lists	145
5-8 Ladder Diagram Instructions	149
5-9 Bit Control Instructions	150
5-10 INTERLOCK and INTERLOCK CLEAR – IL(02) and ILC(03)	155
5-11 JUMP and JUMP END – JMP(04) and JME(05)	157
5-12 END – END(01)	158
5-13 NO OPERATION – NOP(00)	158
5-14 Timer and Counter Instructions	158
5-15 Data Shifting	170
5-16 Data Movement	179
5-17 Data Comparison	191
5-18 Data Conversion	203
5-19 BCD Calculations	227
5-20 Binary Calculations	242
5-21 Special Math Instructions	256
5-22 Logic Instructions	274
5-23 Subroutines and Interrupt Control	278
5-24 Step Instructions	290
5-25 Special Instructions	299
5-26 Network Instructions	317
5-27 Serial Communications Instructions	328
5-28 Advanced I/O Instructions	335
5-29 Special I/O Unit Instructions	349

SECTION 6

Program Execution Timing	357
6-1 Cycle Time	358
6-2 Calculating Cycle Time	362
6-3 Instruction Execution Times	365
6-4 I/O Response Time	374

TABLE OF CONTENTS

SECTION 7

Program Monitoring and Execution 387

- 7-1 Monitoring Operation and Modifying Data 388
- 7-2 Programming Console Operations 388

SECTION 8

Serial Communications 415

- 8-1 Introduction 416
- 8-2 Host Link Communications 417
- 8-3 RS-232C Communications 424
- 8-4 One-to-one PC Links 428
- 8-5 NT Links 430
- 8-6 The Protocol Macro Function 431

SECTION 9

Troubleshooting 441

- 9-1 Alarm Indicators 442
- 9-2 Programmed Alarms and Error Messages 442
- 9-3 Reading and Clearing Errors and Messages 442
- 9-4 Error Messages 443
- 9-5 Error Flags 447
- 9-6 Host Link Errors 448

SECTION 10

Host Link Commands 451

- 10-1 Host Link Command Summary 452
- 10-2 Host Link End Codes 453
- 10-3 Host Link Commands 456

Appendices

- A Standard Models 499
- B Programming Instructions 513
- C Error and Arithmetic Flag Operation 519
- D Word Assignment Recording Sheets 523
- E Program Coding Sheet 529
- F Data Conversion Tables 531
- G Extended ASCII 533

Glossary 535