



# **OPERATING INSTRUCTION MANUAL**

# **MH-250-30**

**MARU KIKAI KOGYO CO., LTD.**

2-4-6, TSUKUDA, CHUO-KU TOKYO 〒104

PHONE : TOKYO 533-0111

# OPERATING MANUAL

## CONTENTS

	Pagi
Mashine Specifications	1-1
Options	1-2
General Drawing	2
Foundation Plan	3
Prohibited Items M/C Summary	4-5
Major Structural Drawing	6
Electrical Specifications	7-11
Installating Conditions for NC	12
NC Console	13
Hydraulic Valves Operating Chart	14-1
Options	14-2
Installation Drawing for Solevoid Valve	15
Ditto for Dimit SW	16
Inspection Procedure	17
Lubrieation Chart	18-19
Hydraulic Circuit Drawing	21-
Parts List for Hydraulics	22-23
Options	24-1
Valve layout Drawing	25
Pneumatic Circuit	26-1
Parts list for Pneumatics	27
Troubleshooting for Hydraulic system	28-31
Line Filters	32-37
Parts List for M/C	38
Ditto for Cylinder	39
Ditto for Bask Guage	40
Ditto for Depth control of Ram	41-1
Options	42-1
Control Unit of Ram stroke	43
Right - left Synchroniging Unit of Ram	44
Slide Way Adjustmwnt of Ram	45
Hydraulic main Cylinder of Ram	46
Hydraulic Return Cylinder of Ram	47
Back Guage Unit	48-49
Depth Control Unit of Ram	50
Option	51-1
Pressing Fovce according to Die Width	52
Tool and Holders	