



OPERATING MANUAL

MHCNC-5000BIII

MARU KIKAI KOGYO CO., LTD.

2-4-6, TSUKUDA, CHUO-KU TOKYO 〒104

PHONE : TOKYO 533-0111

MHCNC-500BIII

Contents

Operating Panel

- Explanation of Panel
- Explanation of Keyboard

Starting Operation

- Preparations Before Operation
- Setting of Origin

Operation

- Operation Example
- Program
- File Setting
- Data Setting
- Position Setting
- Auxiliary Function Setting
- Explanation of Auxiliary Functions
- Tool Setting
- CMT

Running

- Running
- Lower Limit Adjustment and Teaching

Alarms

- Alarms

Maintenance

- Maintenance