

Operation and Maintenance Manual

hmt

**FN2
MILLING MACHINE**

**HMT LTD.
PINJORE 134101
REGD. OFFICE : 36, CUNNINGHAM ROAD
BANGALORE 560052
INDIA**

hmt

OPERATION & MAINTENANCE MANUAL FOR KNEE TYPE MILLING MACHINE FN2

CONTENTS	PAGE
Special Features	3
Operating Controls	4-6
Variants and Specifications	7-9
Standard & Special Accessories	10
Initial Inspection & Preparation of Foundation	11
Foundation Plan & Major Dimensions	12-14
Slinging Diagram	15-16
Levelling & Mains Connection	17
Lubrication and Test-Run	18-24
Coolant System	25
Operation	26-36
Climb Milling Attachment	37-41
Over-load Safety Devices	42-43
Maintenance & Adjustments	44-50
Breakdowns and Remedies	51-54
Schematic Diagrams of Drives	55-61
Electrical System	62
Test Chart	63-73
Spare Parts Manual	74-onwards