

OKK

**OPERATION, MAINTENANCE
& ELECTRICAL**

MHA 350/450/550/650
OKK MIL (M320V)

INSTRUCTION MANUAL

OKK CORPORATION

3-21-9, Toyosaki, Kita-ku
Osaka, Japan

OPERATION MANUAL

.....
MHA 350/450/550/650

OKK MIL (M320V)

OKK

E61-0202/A-SE
91-12-O

Table of Contents

1. Control Panels	1-1
1-1 OKK MIL Main Control Panel Outline	1-1
1-1-1 OKK MIL CRT Display	1-1
1-1-2 OKK MIL Control Panel	1-2
1-1-3 OKK MIL Right Side Control Panel	1-2
1-2 Main Control Panel Function	1-4
2. Manual Handles for 3 Axes	2-1
2-1 Illustration of The 3 Manual Handles	2-1
2-2 Description and Function of Manual Handle Components	2-2
3. PLC Switch Settings	3-1
3-1 PLC switch Display	3-1
3-2 How to Turn Functions ON and OFF	3-2
3-3 Function Descriptions	3-3
4. Load Meter Display (CRT)	4-1
4-1 Selecting The Screen	4-1
4-2 Display Contents	4-1
5. M-Signal Definitions	5-1

**ELECTRICAL
MAINTENANCE MANUAL**

.....

MHA 350/450/550/650
OKK MIL (M320V)

OKK

E61-0202/A-ME
91-11-O

Table of Contents

1 MAINTENANCE SPECIFICATIONS

1-1	Control Panels	1-1
1-1-1	OKK MIL Control Panel	1-1
1-2	Inspection Items	1-2
1-3	Operation Flow Chart	1-3
1-4	Interface- Diagnosis	1-4

2 ALARM MESSAGES

2-1	Alarm Messages	2-1
2-1-1	Alarm Diagnosis Screen	2-1
2-1-2	Alarm Reset	2-2
2-1-3	Alarm Classification	2-2
2-2	Alarm Message Table	2-3
2-2-1	External Alarms	2-4
2-2-2	Spindle Alarms	2-7
2-2-3	Condition Unsatisfied Alarms	2-8
2-2-4	Detector Failure Alarms	2-9
2-2-5	Program/Operating Error Alarms	2-11
2-2-6	Additional Messages	2-12
2-2-7	Spindle Amplifier Error List	2-13

3 MACHINE PARAMETERS

3-1	Machine Parameters	3-1
3-1-1	PLC Constants	3-2
3-1-2	PLC Timer	3-2
3-1-3	PLC Counter	3-7
3-1-4	Bit Selection	3-8