

OPERATION MANUAL

**MACHINING CENTER**

**CONTROL UNIT - MPC2**



**MAKINO MILLING MACHINE CO., LTD.**

## CONTENTS

|                                            | Page |
|--------------------------------------------|------|
| 1. MAIN CONTROL PANEL .....                | 1    |
| 1.1 Emergency Stop .....                   | 3    |
| 1.2 Memory Protect Reset Switch .....      | 3    |
| 1.3 Operation Mode Selector Switches ..... | 4    |
| 1.4 Start and Stop .....                   | 5    |
| 1.5 Machine Display .....                  | 7    |
| 1.6 NC Function Switches and Display ..... | 8    |
| 1.7 Jog Switches .....                     | 9    |
| 1.8 Coolant System .....                   | 11   |
| 1.9 Rotary Switch .....                    | 12   |
| 2. PC SCREEN AND OPERATIONS .....          | 14   |
| 2.1 Type of PC Screen .....                | 14   |
| 2.2 PRIMARY OPERATION Screen .....         | 15   |
| 2.3 Random Data Screen .....               | 32   |
| 2.4 TOOL MONITOR Screen .....              | 36   |
| 2.5 TOOL DETAIL Screen .....               | 41   |
| 2.6 DIAGNS Screen .....                    | 48   |
| 2.7 DATA MAINTN Screen .....               | 49   |
| 2.8 ALARM Screen .....                     | 51   |
| 3. APPENDIX .....                          | 58   |
| 3.1 Alarm List .....                       | 58   |
| 3.2 DI/DO Diagnosis Table .....            | 117  |

# **TOOL MONITOR**

**(FS11M, MPC2 SPECIFICATIONS)**

## CONTENTS

|                                                          | Page |
|----------------------------------------------------------|------|
| 1. GENERAL .....                                         | 1-1  |
| 2. ADAPTIVE CONTROL (AC) .....                           | 2-1  |
| 2.1 Introduction .....                                   | 2-1  |
| 2.2 Study Function (STUDY) .....                         | 2-1  |
| 2.3 Spindle Load Monitor .....                           | 2-3  |
| 2.4 Adaptive Control .....                               | 2-4  |
| 2.5 Programming Example .....                            | 2-5  |
| 3. TOOL LIFE MONITOR (TL) .....                          | 3-1  |
| 3.1 Introduction .....                                   | 3-1  |
| 3.2 Tool Life Monitor .....                              | 3-1  |
| 4. BROKEN TOOL SENSOR (BTS) .....                        | 4-1  |
| 5. ACOUSTIC EMISSION MONITOR (AE) .....                  | 5-1  |
| 6. SPARE TOOL SELECTION (STS) .....                      | 6-1  |
| 7. AUTOMATIC WORK REJECT FUNCTION (AWR) .....            | 7-1  |
| 8. CONDITIONS FOR MODE SELECTION BETWEEN FUNCTIONS ..... | 8-1  |
| 9. DISPLAY AND OPERATIONS OF TOOL MONITOR SCREEN .....   | 9-1  |
| 9.1 TOOL MONITOR Screen .....                            | 9-1  |
| 9.2 TOOL DETAIL Screen .....                             | 9-5  |
| 10. TOOL MONITOR ALARMS .....                            | 10-1 |
| 11. M FUNCTION OF TOOL MONITOR .....                     | 11-1 |
| 12. TOOL MONITOR SETUP PARAMETERS .....                  | 12-1 |