


MUTECH[®]

SAFETY INSTRUCTION MANUAL

Model: MT-850V/VS

VERTICAL MACHINING CENTER



Company : Shou Zuan Precision Machinery Co., Ltd.

Address : No. 3, Alley 76, Lane 283, Shui Yuan Rd., Fong Yuan
District, Taichung City, Taiwan, R.O.C.

TABLE CONTENT

1. Introduction to the machine.
 - 1.1. Machine features
 - 1.2. Machine outlook and part name
 - 1.3. Overall drawing for main dimensions
 - 1.4. Coordinate system
 - 1.5. Machine specification
2. Explanation for the mechanical structure
 - 2.1. Mechanical structure
 - 2.2. Machine frame
 - 2.3. Spindle
 - 2.4. Feeding for 3 axis
 - 2.5. Tool magazine
 - 2.6. ATC Troubleshooting (ARM MODEL)
 - 2.7. Big Tool Diameter Setting
3. Safety precautions
 - 3.1. Safety precautions for operation
 - 3.2. Safety precautions for machinery
 - 3.3. Safety precautions for the electric
4. Machine installation and testing
 - 4.1. General information for machine installation
 - 4.2. Requirement for power connection
 - 4.3. Requirement for the pneumatic supply
 - 4.4. Leveling adjustment
 - 4.5. Precautions for the first start after installation
 - 4.6. Explanation for the safety system of movable door
 - 4.7. Operation mode
 - 4.8. Application and prohibition of operation
5. Information for machining
 - 5.1. Dimensions of working table
 - 5.2. Max. dimension of work piece.
6. Panel operating instructions
 - 6.1. Function Description
7. Inspection and maintenance.
 - 7.1. Periodic inspection and maintenance
 - 7.2. Cleaning instructions
 - 7.3. Recommended fluid for this machine
 - 7.4. Preparation before installation
 - 7.5. Maintenance of high point
8. Additional information
 - 8.1. M-CODE list
 - 8.2. Regular check of warning device
 - 8.3. Information of airborne noise
 - 8.4. Handling
 - 8.5. Residual risk.
9. Parts List