

# PARTS MANUAL

**NC ELECTRICAL DISCHARGE MACHINE**

# **EDGE**

MAKINO MILLING MACHINE CO., LTD.

16ED1-ME01-9305(E)

# PARTS MANUAL

**EDGE 1**

HEAD UNIT

16ED 10A

MAKINO MILLING MACHINE CO., LTD.

# PARTS MANUAL

## EDGE 1

MA-HEAD UNIT

16ED 13A

MAKINO MILLING MACHINE CO., LTD.

# PARTS MANUAL

EDGE 1

RAM UNIT

16ED 20A

MAKINO MILLING MACHINE CO., LTD.

# PARTS MANUAL

## EDGE 1

SADDLE UNIT

16ED 30A

MAKINO MILLING MACHINE CO., LTD.

# **PARTS MANUAL**

## **EDGE 1**

**BED UNIT**

**16ED 40B**

**MAKINO MILLING MACHINE CO., LTD.**

# PARTS MANUAL

## EDGE 1

TABLE UNIT

16ED 50B

MAKINO MILLING MACHINE CO., LTD.

# PARTS MANUAL

## EDGE 1

WORK TANK UNIT

16ED 60A

MAKINO MILLING MACHINE CO., LTD.

# **PARTS MANUAL**

## **EDGE 1**

**DIELECTRIC SUPPLY UNIT**

**16ED 80A**

**MAKINO MILLING MACHINE CO., LTD.**

# PARTS MANUAL

## EDGE 1

ATC BASE UNIT

16ED 500B

MAKINO MILLING MACHINE CO., LTD.

# PARTS MANUAL

## EDGE 1

MAGAZINE UNIT  
(8 PIECES)

16ED 530B

MAKINO MILLING MACHINE CO., LTD.

# PARTS MANUAL

## EDGE 1

MAGAZINE UNIT  
(16 PIECES)

16ED 531B

MAKINO MILLING MACHINE CO., LTD.

# PARTS MANUAL

## EDGE 1

MAGAZINE UNIT  
(4 PIECES)

16ED 536B

MAKINO MILLING MACHINE CO., LTD.

# **PARTS MANUAL**

## **EDGE 1**

**ATC OPERATION BOX UNIT**

**16ED 540B**

**MAKINO MILLING MACHINE CO., LTD.**

# PARTS MANUAL

## EDGE 1

CHACK CONTROLLER UNIT

16ED 545B

MAKINO MILLING MACHINE CO., LTD.