

ALPHALINK
SOFTWARE
INSTRUCTION
MANUAL



SOFTWARE INSTRUCTION MANUAL



ENGLISH
VERSION 5.1

Contents

Introduction	2
Installation	3
The Main Menu	4
Using The Alpha-link Module	5
Starting A Drawing.....	6
Screen Layout.....	8
Moving Around The Screen	9
Drawing Commands - CAD	11
All Drawing Options	12
Machining Commands - CAM	34
All Machining Options	35
Exiting The Cam System	53
File Handling	54
Advanced Alpha-Link Programming	55
Download CAM to the Alpha Machine.....	60
ISO Program Editor	63
Save/Load ISO Programs	65
Print Module.....	67
Tool Library Editor	69
Save/Load Manual Operations	75
DXF Conversion & Input.....	77
Copy To/From Floppy Disk.....	79
User Definable Directories	83
Drawing Paths Module	84
Problems And Support	86
Computer Talk	88

