## **OPERATION MANUAL**

## Applicable Model

CL-153, 153M CL-203, 203M CL-253 SL1000 SL2500Y

Applicable NC Unit

MSG-803 MSG-805

Before starting operation, maintenance, or programming, carefully read the manuals supplied by Mori Seiki, the NC unit manufacturer, and equipment manufacturers so that you fully understand the information they contain.

Keep the manuals carefully so that they will not be lost.

## **CONTENTS**

FOR SAFE OPERATION

WARNING DISPLAY ON TURNING ON POWER

**PREFACE** 

SIGNAL WORD DEFINITION

FLOW UNTIL THE PRODUCT IS COMPLETED

DOOR INTERLOCK, FUNCTION

A: OPERATION PANELS

**B**: MANUAL OPERATION

C: CHUCKING

D: PROGRAM EDITING

**E:** SETTING OF COORDINATE SYSTEM

F: PREPARATION BEFORE STARTING MASS PRODUCTION

INDEX