

OPERATING MANUAL & PARTS LIST

**CH - 400 x 800
400 x 1100
400 x 1700
430 x 800
430 x 1100
430 x 1700
530 x 800
530 x 1100
530 x 1700**

**(CH - 1631, 1643, 1667
1731, 1743, 1767
2031, 2043, 2067)**



CHIN HUNG MACHINERY CO., LTD. (KINWA)
NO. 5-4, TIEN SHIN LANE, YA TARN RD.
TA-YA, TAICHUNG, TAIWAN
TEL:(04)5666113-4·5663114-5 FAX:04-5665254
P.O.BOX:22-44 TAICHUNG TAIWAN.

CONTENTS

I Contents of Operating Manual

I.	PREFACE	
II.	SPECIFICATIONS	
1.	INSTALLATION	1
1-1.	HANDLING	1
1-2.	UNPACKING	1
1-3.	LIFTING	1
1-4.	CLEANING	3
1-5.	LEVEL ADJUSTMENT	3
2.	LUBRICATION	4
3.	DESCRIPTION	6
3-1.	MACHINE PART IDENTIFICATION	6
3-2.	IDENTIFICATION CONT'D	7
4.	PREPARATION FOR OPERATION	8
4-1.	ELECTRICAL WIRING	8
4-2.	PREPARATION BEFORE STARTING	8
5.	HEADSTOCK	9
5-1.	HOUSTING	9
5-2.	SPINDLE	9
5-3.	SPINDLE BEARING ADJUSTMENT	9
5-4.	OPERATION	10
6.	QUICK CHANGE GEAR BOX	10
6-1.	FUNCTION	10
6-2.	OPOERATION	11
6-3.	THREAD & FEED CHARTS	12
6-4.	THE EXAMPLE OF THREAD CUTTING OPERATION	13
6-5.	OPERATION (Q.C. GEAR BOX)	14
6-6.	SAFETY FEATURES	15
6-7.	THREAD DIAL INDICATOR	16
6-8.	SPECIAL THREADS CUTTING	17
7.	APRON	17
7-1.	FUNCTION	17
7-2.	FEEDS	18
7-3.	THREADING	19
8.	CARRIAGE CROSS SLIDE & COMPOUND SLIDE	20
8-1.	DESCRIPTION	20
8-2.	TAPERED GIBS	20
8-3.	OPERATION	20
8-4.	CROSS SLIDE	21
8-5.	COMPOUND SLIDE	22

9.	TAILSTOCK	22
9-1.	DESCRIPTION	22
9-2.	ADJUSTMENT	23
10.	ELECTRICAL	24
10-1.	DESCRIPTION	24
10-2.	CONTROLS IDENTIFICATION/LOCATION	24
10-3.	OPERATION	25
10-4.	WIRING/CONNECTING.	25
	ELECTRIC DISTRIBUTION DIAGRAM(4P)(12S & 8S) GENERAL	26
10-5.	ELECTRICAL TROUBLE SHOOTING GUIDE	29
11.	TROUBLE SHOOTING GUIDE	30
12.	MAINTENANCE & ADJUSTMENTS	31
12-1.	HEADSTOCK REALIGNMENT	31
12-2.	DRIVE BELTS	32
12-3.	BRAKE ADJUSTMENT	33
12-4.	CARRIAGE BIG ADJUSTMENT	34
III.	PARTS LIST	
1.	HEADSTOCK (12-S) 430 (17")	35
2.	FEED GEAR BOX	43
3.	CARRIAGE	50
4.	APRON	56
5.	TAILSTOCK	63
6.	ASSEMBLY OF BED AND LEG	66
6-1.	ASSEMBLY OF BED AND LEG (COOLANT SYSTEM)	72
7.	BRAKE MECHANISM	74
8-1.	QUADRANT (12-S & 8-S) INCH SYSTEM	77
8-2.	QUADRANT (12-S & 8-S) METRIC SYSTEM	79
9.	ATTACHMENT	81
9-1.	FOLLOWER REST	81
9-2.	STEADY REST	81
9-3.	MICRO CARRIAGE STOP	84
9-4.	DRILLING ATTACHMENT	86
9-5.	TURRET CARRIAGE STOP	88
9-6.	INFED PLUNGE CUTTING ATTACHMENT	90
9-7.	TAPER TURNING ATTACHMENT	92
9-8.	COLLET CHUCK	95
9-9.	FACE PLATE AND CHUCK	97
1.	HEADSTOCK (8-S) 400 (16")	98
	ELECTRIC DISTRIBUTION DIAGRAM (4P/8P)(8S) SPECIAL	105