

Manual

ToPs 200

Programming system for
punching, nibbling, forming

TRUMPF



Manual

ToPs 200

Version 2.0

Programming System for
Punching, Nibbling, Forming

Edition: **01/96**



Table of Contents

Chapter 1 ToPs 200: Introduction to the programming system

1.	ToPs under WINDOWS	1-3
2.	Concept	1-4
	Basic Idea: Flexibility	1-6
	Flexible Definition of Machining Operations	1-6
	Flexible Editing	1-8
	Flexible Programming Sequence	1-9
	Parameterizable Postprocessor	1-10
	Degree of Automation	1-10
	Machining directions	1-11
	Making Sample Parts	1-11
	Preparing for single part processing at the machine.....	1-12
	Repositioning	1-13
	Tooling.....	1-14
3.	Modular Structure	1-15
	Brief Description of the Modules	1-15
4.	Programming with ToPs	1-23
	Programming Sequence: From the Concept to the Final NC Program.....	1-23
5.	Files in ToPs	1-25



Chapter 2 Using ToPs

1.	Different Computer Platforms, Different Modules - Uniform Handling	2-2
2.	Starting and Quitting ToPs	2-2
2.1	Workstation.....	2-3
2.2	PC	2-6
2.3	Setting the Language Version	2-8
3.	Operating Elements: Mouse and Keyboard	2-9
3.1	Mouse	2-9
3.2	Keyboard	2-11
4.	User Interface	2-12
4.1	Central Switchboard: The Initial Screen	2-12
4.2	Screen Layout within the Modules.....	2-13
4.2.1	Title Area	2-14
4.2.2	Main Menu Bar	2-14
4.2.3	Work Area	2-15
	Graphic Display.....	2-15
	Mask Display	2-17

Chapter 3 Basics: Standard Functions

1.	A Continuous Thread: Standard Functions	3-3
2.	Key Functions	3-4
2.1	Using F Keys as Hotkeys	3-4
2.2	Repeating Inputs and Functions.....	3-6
3.	Fixed Screen Menus	3-7
4.	Graphic Display: Marking Elements	3-10
4.1	Marking elements	3-10
4.2	Enlarging element display	3-11

5.	Mask Display: Basic Functions	3-12
5.1	Data Input	3-12
5.2	Data Selection.....	3-14
5.3	Switches	3-16
5.4	Function Buttons.....	3-16
6.	Standard Masks	3-17
6.1	Loading and Storing Files: File Selector Masks.....	3-17
6.2	Acknowledging Messages: Message Box.....	3-21

Chapter 4 **Module DRAWING**

1.	Creating or Loading Drawings in ToPs	4-3
2.	Creating a Single Part Drawing: Overview of Functions	4-4
	Functions in the Main Menu Bar.....	4-4
	Screen Menu Functions.....	4-4
3.	Creating a Single Part Drawing: Different Procedures	4-7
	Basics	4-7
	Basic Rules: Creating Drawings with ToPs	4-8
	Creating a New Single Part Drawing	4-9
	Loading/Importing, Processing, and Storing an Existing Drawing	4-10
4.	Functions in the Main Menu Bar	4-11
4.1	Loading and Importing a Drawing.....	4-11
	Importing Drawings	4-12
4.2	Storing a Drawing.....	4-13
4.3	Inserting (Drawing) Text in Drawings	4-16
5.	Functions in the Screen Menus	4-18
5.1	DRAW 1 and 2: Drawing Geometrical Elements.....	4-18
5.2	DRAW 2: Measuring	4-33
5.3	DRAW 2: Preparing a Drawing.....	4-35
5.4	DRAW 2: Single Hole, Row of Holes, Bolt Circle	4-36
5.5	DRAW 3: Creating Construction Geometry.....	4-42

5.6	DRAW 4: Editing Geometry	4-50
5.7	DRAW 5: Auxiliary Functions	4-59
5.8	HARDCOPY: Printing Drawings	4-66

Chapter 5 Module MINI NEST

1.	What is a Mini Nest?	5-2
2.	Creating a Mini Nest: Overview of Functions	5-3
3.	Creating Mini Nests: Different Procedures	5-5
	Creating a New Mini Nest.....	5-5
	Loading, Modifying and Storing Existing Mini Nests	5-6
4.	Functions in the Main Menu Bar: Creating, Loading and Storing Mini Nests	5-7
5.	Functions in the Screen Menu: Modifying a Mini Nest	5-9

Chapter 6 Module SHEET

1.	The Nesting Processor: Function.....	6-3
2.	Sheet Layout: Overview of Functions	6-5
3.	Sheet Layout: Procedure.....	6-7
	Generating a Sheet	6-7
	Displaying the Nesting Result	6-7
	Editing the Nesting Result Manually	6-8



4.	Functions in the Main Menu Bar	6-9
4.1	Creating a Nesting Job	6-9
4.2	Nesting Start	6-19
4.3	Manual Nesting.....	6-31
4.4	Outputting the Nesting Results	6-33
4.5	Loading the Machine Drawing	6-36
	Editing the machine drawing	6-37
5.	Functions in the Screen Menus.....	6-38
5.1	NESTING 1: Information - Deleting and Adding parts.....	6-38
5.2	NESTING 2: Editing Parts.....	6-42
5.3	NESTING 3: Displaying the Machine Environment, Measuring.....	6-44

Chapter 7 Module TECHNOLOGY

1.	Flexible Definition of Machining, NC Program Generation.....	7-4
	Machining Strategies	7-5
2.	Overview of Functions	7-8
3.	Programming Procedures.....	7-11
4.	Graphic Display: Significance of Colours and Symbols	7-15
5.	Selecting a Machine	7-16
	Basic Machines and Machine Types.....	7-16
	Selecting the Machine: Procedure	7-19
	Choosing Other Machines.....	7-21
6.	Loading and Saving files.....	7-22
	Loading Files	7-23
	Saving Files	7-24
7.	Tools.....	7-25
	Overview: Which Tool for Which Machining Operation?	7-25
7.1	Activating Tools.....	7-26
7.2	Tool Selection Window	7-28

7.3	Displaying the Tools Used.....	7-30
7.4	Tool Lists.....	7-32
7.5	Tool Data Management.....	7-36
8.	Definition of Machining.....	7-37
8.1	Menus PROCESSING 1 and PROCESSING 1-2.....	7-41
	AUTOCUT: Automatic processing definition	7-42
	Creating Machining Operations in the Menu PROCESSING 1.....	7-50
	Overlapping.....	7-53
	Parts/Scrap Removal.....	7-55
	Tooling.....	7-64
	Creating Machining Operations in the Menu PROCESSING 1-2.....	7-65
	Cutting Scrap to Pieces	7-67
	Deleting Machining Operations.....	7-70
8.2	Menu PROCESSING 2	7-71
	Modifying Machining Operations.....	7-71
	Compulsory Sequences	7-73
8.3	Menu PROCESSING 3	7-77
8.4	Menu PROCESSING 4	7-78
	Switching Functions.....	7-78
	Thread Forming and Engraving.....	7-85
	Setting Punching Mode Data.....	7-87
	Repositioning	7-88
8.5	Menu PROCESSING 5	7-92
	Simulation of Machining Operations.....	7-94
8.6	Transferring Single-Part Machining to the Sheet	7-96
9.	Sheet Layout	7-98
	Sheet Layout in the TECHNOLOGY Module	7-98
	Defining Sheet Data	7-100
9.1	Menu SHEET NESTING 1: Multiple-Copy Machining, Delete Functions.....	7-101
	Multiple-Copy Machining	7-102
	Sheet Layout: Delete Functions.....	7-108
9.2	Menu SHEET NESTING 2: Modifying the Position of a Part	7-109
9.3	Menu SHEET NESTING 3: Construction Geometry, Measuring	7-110
9.4	Menu SHEET NESTING 4: Clamp Position, Sheet Size, Loading Position	7-111
9.5	Menu SHEET NESTING 5: Hardcopy, Presettings ...	7-113



10.	Sheet optimization.....	7-114
	Overview of functions	7-114
10.1	Automatic sheet optimization	7-115
10.2	Interactive sheet optimization	7-121
11.	Generating NC Programs and Checking Them....	7-125
11.1	Flexible sheet layout at the machine	7-128
	Programming in ToPs 200	7-129
	Operation at the machine	7-137
11.2	Checking the NC Program	7-144
11.3	Displaying and Printing the Set-Up Plan	7-145
11.4	Displaying and Printing the NC Program.....	7-147

Chapter 8 **Module DATA**

1.	Data Base Administration.....	8-2
2.	Machine Data Entry	8-4
	Modifying, Copying, Deleting, Creating Machines	8-5
2.1	Changing the Machine Configuration	8-7
2.2	Modifying Machine Data	8-10
3.	Material Data Entry.....	8-35
4.	Rules.....	8-37
5.	NC Output.....	8-38
5.1	Modifying Machining Times.....	8-38
5.2	Support Functions	8-41
6.	Tool Data Entry	8-42
6.1	Tool Administration	8-43
	Tool data entry.....	8-44
	Modifying Tool Data, Deleting Tools.....	8-55
	Changing / Deleting Tool Types	8-58
6.2	Creating Tool Drawings	8-59

Chapter 9 Module SYSTEM

1.	System Management (Overview)	9-2
2.	Functions in the SYSTEM Module	9-3
	Overview of Functions.....	9-3
	Directory Management.....	9-4
	Displaying Files.....	9-5
	Data Transfer.....	9-6
	Displaying a Message List.....	9-8

Chapter 10 Automation Components

1.	Automation Components in ToPs 200	10-3
2.	Defining the Machine Configuration	10-3
3.	TRUMALIFT SheetMaster	10-6
3.1	Module TECHNOLOGY: Defining Removal of Parts and Scrap with the TRUMALIFT SheetMaster.....	10-7
	Procedure.....	10-7
	Removal with the TRUMALIFT SheetMaster.....	10-9
	Overview of Removal Functions.....	10-12
	Menu PARTS/SCRAP REMOVAL LIFT.....	10-13
	Menu UNLOADING AREA.....	10-22
3.2	Module DATA.....	10-31
	Entering Data for the TRUMALIFT SheetMaster.....	10-32
	Machine Configuration.....	10-33
	Modifying Machine Data.....	10-35
4.	TRUMAGRIP	10-47
	Programming the TRUMAGRIP 500.....	10-47
	Modifying TRUMAGRIP Data.....	10-48
5.	TRUMASORT	10-52
5.1	TRUMASORT R4/S.....	10-52
5.2	TRUMASORT L.....	10-54

6.	Basic Data in ToPs 200 - Overview	10-59
	Data Sheets.....	10-59
	Data Sheet for TRUMALIFT SheetMaster 1250:	
	Loading	10-60
	Data Sheet for TRUMALIFT SheetMaster 1250:	
	Unloading.....	10-61
	Data Sheet for TRUMALIFT SheetMaster 1300:	
	Loading and Unloading	10-62
	Data Sheet for TRUMALIFT SheetMaster 1600:	
	Loading and Unloading	10-64
	Input Forms	10-66
	Lift parameters in ToPs 200.....	10-75

Chapter 11 Additional Functions (Options)

1.	Option: Importing Drawings	
	IGES Interpreter	
	DXF Interpreter	
	MI Interpreter	
	GRA Interpreter.....	11-3
1.1	Importing	11-3
	Procedure.....	11-4
1.2	Generating DXF Files.....	11-9
1.3	Automatic Module for Converting	
	CAD Files	11-10
	The 'convert.exe' Program	11-10
	Procedure.....	11-11
	Examples.....	11-13
	Background Information: Options for the	
	Command 'convert.exe'	11-14
2.	Option: Free shape nesting processor	11-16
2.1	The nesting processors in comparison	11-16
2.2	Free shape nesting of parts	11-17
	Choosing the nesting strategy.....	11-18
	Nesting remainder sheets	11-19
	Saving and loading the nesting job as a file	11-20