


KENT

Technology · Creativity · Reliability
Smooth your way to success

SURFACE GRINDER

*SERVICE AND INSTRUCTIONS MANUAL FOR
MAINTENANCE AND PARTS LIST*

KGS-410/515/620AH.AHD



KENT INDUSTRIAL CO., LTD.

CONTENTS

	Page
A. Transition.....	1
B. Unpacking.....	1
C. Choice Of Site	
(1). KGS-410AH(AHD) Floor Plan.....	3
(2). KGS-515AH(AHD) Floor Plan.....	4
(3). KGS-620AH(AHD) Floor Plan.....	5
D. Installation	
(1). Power Consumption.....	6
(2). Foundation.....	6
(3). Levelling The Machine.....	9
(4). Contour And Nomenclature.....	10
(5). Table Size And Grinding Capacity.....	16
(6). Lubrication Instruction.....	17
(7). Circuit Diagram And Connection Diagram.....	19
(8). Hydraulic System.....	27
(9). Limit Switch Position.....	34
(10). Balancing The Grinding Wheel.....	36
E. Putting The Machine Into Operation	
(1). Wire Connection.....	38
(2). KGS-410AH, 515AH, 620AH	
a). Control Panel & Description.....	40
b). Operation.....	41
(3). KGS-410AHD, 515AHD, 620AHD	
a). Control Panel & Description.....	43
b). Operation.....	44
F. General Comments Of Grinding.....	46
G. Wheel Inspection.....	46
H. Dressing The Wheel And Correct Treatment Of Dressing Diamond.....	47
I. Storage Of Grinding Wheels.....	48
J. Selection Of Suitable Grinding Wheels.....	48
K. Wheel Be Recommended.....	50
L. Choice Of The Grinding Conditions.....	50
M. Use Of The Optional Attachment	
(a). Parallel Dressing Attachment (Standard Accessory)	52
(b). Angle Forming Attachment.....	52
(c). Sine Bar.....	53
(d). Radius Forming Attachment.....	53
(e). Coolant System (Standard Accessory).....	55

	Page
(f). Common Cases In Side Grinding.....	56
(g). Right Angle Grinding.....	56
N. Complete Knockdown Drawing & Parts Lists.....	58
O. Electric Parts List.....	96
P. Trouble Shooting	
(1). Grinding Defects.....	100
(2). Operation Defects.....	101
(3). For KGS-410AHD, 515AHD, 620AHD.....	102
Q. Inspection Chart.....	104