

Mazak

OPERATING MANUAL

for

MAZATROL FUSION 640T

(OPERATING NC UNIT AND PREPARATION
FOR AUTOMATIC OPERATION)

2-axis Specification

MANUAL No. : H734S30045E

**OPERATING
MANUAL**



OPERATING MANUAL

for

MAZATROL FUSION 640T

(OPERATING NC UNIT AND PREPARATION
FOR AUTOMATIC OPERATION)

2-axis Specification

MANUAL No. : H734S30045E

Serial No. :

Before using this machine and equipment, fully understand the contents of this manual to ensure proper operation. Should any questions arise, please ask the nearest Technical/Service Center.

IMPORTANT NOTICE

1. Be sure to observe the safety precautions described in this manual and the contents of the safety plates on the machine and equipment. Failure may cause serious personal injury or material damage. Please replace any missing safety plates as soon as possible.
2. No modifications are to be performed that will affect operation safety. If such modifications are required, please contact the nearest Technical/Service Center.
3. For the purpose of explaining the operation of the machine and equipment, some illustrations may not include safety features such as covers, doors, etc. Before operation, make sure all such items are in place.
4. This manual was considered complete and accurate at the time of publication, however, due to our desire to constantly improve the quality and specification of all our products, it is subject to change or modification. If you have any questions, please contact the nearest Technical/Service Center.
5. Always keep this manual near the machinery for immediate use.
6. If a new manual is required, please order from the nearest Technical/Service Center with the manual No. or the machine name, serial No. and manual name.

Issued by *Manual Publication Section, Yamazaki Mazak Corporation, Japan*

CONTENTS

	Page
1 PREPARATION FOR AUTOMATIC OPERATION	1-1
1-1 Preparation Steps for Automatic Operation	1-1
2 DISPLAY OVERVIEW	2-1
2-1 Name of the Components of Each Display	2-1
2-2 Types of Displays	2-4
2-3 DISPLAY MAP Display	2-5
2-4 Windows	2-6
2-5 Task Bar of "Windows"	2-8
3 DATA SETTING METHODS.....	3-1
3-1 Setting Data and Address.....	3-2
3-2 Selecting Menu Data	3-3
3-3 Erasing Data	3-3
3-4 Modifying Data.....	3-4
3-5 Incremental Input.....	3-4
3-6 Saving Data onto the Hard Disk.....	3-4
4 DISPLAYS RELATED TO THE MACHINE OPERATIONAL STATUS	4-1
4-1 POSITION Display.....	4-1
4-2 MEASURE Display	4-6
4-3 EIA MONITOR Display	4-9
4-4 MACHINING - MONITORING Display	4-12

4-5 MACHINING NAVIGATION - RESULT Display	4-17
5 DISPLAYS RELATED TO MACHINING SET UP	5-1
5-1 SET UP MANAG. Display	5-1
5-2 TRACE Display	5-14
5-3 SET UP RECORD Display	5-18
5-4 CHUCK JAW DATA Display	5-22
5-5 SPINDLE LOAD GRAPHIC DISPLAY Display	5-24
6 DISPLAYS RELATED TO PROGRAM CREATION	6-1
6-1 PROGRAM Display	6-1
6-2 SHAPE CHECK Display	6-2
6-3 TOOLPATH Display	6-4
6-4 PROCESS LAYOUT Display	6-17
6-5 TPC EDIT Display	6-23
6-6 PROGRAM FILE Display	6-25
6-7 MACHINING NAVIGATION - PREDICT Display	6-30
7 DISPLAYS RELATED TO TOOLS	7-1
7-1 TOOL DATA Display	7-1
7-2 TOOL OFFSET Display	7-26
7-3 TOOL LIFE Display	7-32
8 DISPLAYS RELATED TO PARAMETERS	8-1
8-1 CUTTING CONDITION (REGIST) Display	8-1
8-2 CUTTING CONDITION (PERCENTAGE) Display	8-4

8-3	CUTTING CONDITION (TURNING) Display	8-6
8-4	CUT LEARN Display.....	8-8
8-5	USER PARAMETER Display.....	8-10
8-6	MACHINE PARAMETER Display	8-11
8-7	WORK OFFSET Display.....	8-12
8-8	MACRO VARIABLE Displays	8-16
9	DISPLAY RELATED TO DATA STORAGE	9-1
9-1	DATA I/O Display.....	9-1
9-1-1	Display operations.....	9-2
9-1-2	Data input/output in text file format	9-21
10	DISPLAYS RELATED TO DIAGNOSIS	10-1
10-1	DIAGNOSIS (ALARM) Display	10-2
10-2	DIAGNOSIS (ALARM HISTORY) Display.....	10-3
10-3	DIAGNOSIS (PLC SIGNAL) Display.....	10-4
10-4	MAINTENANCE CHECK Display	10-5
10-4-1	Data display for normal check items	10-5
10-4-2	Data display for long-term check items (1500 and 3000 hours check items).....	10-6
10-5	RUNNING CONTROL Display.....	10-7
10-6	DIAGNOSIS (VERSION) Display.....	10-12
10-7	DIAGNOSIS (MONITOR) Display.....	10-13
10-8	DIAGNOSIS (OPTION) Display	10-17
10-9	DATA ERASE Window	10-18
10-10	ACCUMULATED TIME Window	10-18