

ARD ELECTRIC DISCHARGE MACHINE
INSTRUCTION MANUAL

E-TYPE

VER: 1.0



ISSUED DATE : JUN. 1997

亞特精密機械股份有限公司
ARD PRECISION MACHINERY CO.,LTD.

282 CHUNG SHAN 1ST ROAD, LU CHOU TAIPEI HSIEN, TAIWAN, R.O.C.
TEL: (02)281-9745 FAX: (02)281-8917

MACHINE TOOL

CONTENTS

CHAPTER 1	SPECIFICATIONS	3
1-1	Machine	
1-2	Power supply	
1-3	Dielectric tank	
1-4	Standard accessories	
1-5	Optional accessories	
CHAPTER 2	UNPACKING	5
CHAPTER 3	TRANSPORTATION	6
CHAPTER 4	OPERATION STTE	8
4-1	Operating site	
4-2	Machine installation diagram	
4-3	Power required	
4-4	Horizontal adjustment	
4-5	Degreasing	
CHAPTER 5	INSTALLATION	1 0
5-1	Dielectric tank	
5-2	Power supply unit connections	



CHAPTER 6 CHECKING DIELECRTCIC CIRCUIT
..... 1 3

CHAPTER 7 DIELECTRIC CIRCULATION
INSTRUCTION 1 4

CHAPTER 8 MACHINE OPERATION 1 6

- 8-1 Up-down movement of workhead
- 8-2 X-Y Movement of work table
- 8-3 Work tank
- 8-4 Machine start
- 8-5 Edge finder
- 8-6 System 3R-Accessories for standard
EDM
- 8-7 Electrical centering
- 8-8 Depth stop
- 8-9 Closing work tank door
- 8-10 Flushing
- 8-11 Setting control panel

CHAPTER 9 MAINTENANCE, CLEANING
& LUBRICATION 2 6

- 9-1 Fluid level check
- 9-2 Lubrication
- 9-3 cleaning

CHAPTER 10 M30E,M50E MECHANICAL ELEMENT
CODE 2 8



POWER SUPPLY UNIT

P30 P50 POWER SUPPLY UNIT

CHAPTER 1	ART POWER SUPPLY INTRODUCTION	• • • • • 2
CHAPTER 2	EDM PRINCIPLES AND TECHNOLOGY	• • • • • 3
CHAPTER 3	ELECTRODE MATERIAL • • • • •	5
3-1	Electrode material characteristics	
3-2	Production method of electrode	
CHAPTER 4	EDM APPLICATION • • • • •	8
CHAPTER 5	M30E,M50E CONTROL PANEL • • •	1 1
5-1	"BT" high voltage amperage control knob	
5-2	"AT" low voltage amperage control knob	
5-3	"PA" pulse duration knob	
5-4	"PB" interval knob	
5-5	Servo sensitivity adjustment knob	
5-6	Discharge gap adjustment knob	
5-7	Workhead vertical movement adjustment knob	
5-8	Optional functions for poor flushing	
5-9	Indicator lamp	
5-10	Other switches with indicator lamp	
5-11	Other push buttons	
5-12	Buzzer and discharge timer	
5-13	Main switch & Emergency stop	
5-14	Working light operation manual	
	Lighting equipment for both normal operation and fire alarm	
5-15	Fire alarm system	

P30

P50

APPLICATION NOTE

P30
P50 APPLICATION NOTE

INDEX

CHAPTER 1 SURFACE FINISH IN EDM	2
CHAPTER 2 (90V) ELECTROLYTIC COPPER(+) - STEEL	3
CHAPTER 3 (90V) GRAPHITE(+) - STEEL	1 0
CHAPTER 4 (260V) ELECTROLYTIC COPPER(-) - STEEL	1 5
CHAPTER 5 (90V) COPPER TUNGSTEN(-) - TUNGSTEN CARBIDE (Can be refered as copper to tungsten carbide application)	1 6
CHAPTER 6 (90V) ELECTROLYTIC COPPER(-) - COPPER	1 7
CHAPTER 7 (260V,90V) STEEL(+) - STEEL	1 9
CHAPTER 8 (260V,90V) ELECTROLYTIC COPPER(+) - STEEL	2 1

