



**YCM-TV116A/TV146A**

**MECHANICAL MANUAL**

**VERTICAL MACHINING CENTER**

**YEONG CHIN MACHINERY INDUSTRIES CO., LTD.**

HEADQUARTERS : 888, HOMU RD., HSINCHUANG  
SHENKANG, TAICHUNG, TAIWAN

TEL : 886-4-25623211 FAX : 886-4-25626479 . 886-4-25628399  
SERVICE TEL : 886-4-25612965 FAX : 886-4-25612966

E-mail : sales@YCMCNC.com

Web site : <http://www.YCMCNC.com>

ENDEAVORING TO CONFORM THE ISO 14001 ENVIRONMENTAL PROTECTION POLICIES;  
IN PURSUIT OF EXCELLENCE; ALWAYS IMPROVING AND REFINING.

# CONTENTS

PREFACE	PAGE
<b>CHAPTER 1 INSTRUCTION FOR SAFETY</b>	
1-1 Basic instruction for safe operation .....	1-1~1-2
1-2 Symbols and designations connected with safety .....	1-3
1-3 Safety precautions .....	1-4
1-3-1 Basic operatin practices .....	1-4
1-3-2 Before switching on .....	1-4~1-5
1-3-3 After control power switch has been turned on .....	1-5
1-3-4 Routine inspections .....	1-5
1-3-5 Warm up .....	1-5
1-3-6 Preparations .....	1-5~1-6
1-3-7 Operation .....	1-6
1-3-8 To interrupt machining .....	1-6
1-3-9 Completing a job .....	1-7
1-3-10 Safety devices .....	1-7
1-3-11 Maintenance operation reparations .....	1-7
1-3-12 Maintenance operation .....	1-7
1-3-13 Until operation is begin after maintenance .....	1-7
1-4 Danger areas .....	1-8
1-4-1 Area with moving parts .....	1-9~1-11
1-4-2 High voltage areas .....	1-12~1-15
1-5 Safety device .....	1-16
1-5-1 Warning plates position .....	1-17~1-19
1-5-2 Instruction plates position .....	1-20~1-25
1-5-3 I.D name plate of machine .....	1-26
<b>CHAPTER 2 DESCRIPTION OF MACHINE</b>	
2-1 Function and fields of application .....	2-1
2-2 Specification .....	2-2~2-7
2-3 Accessories .....	2-8
2-4 Airbond noise .....	2-9
2-5 Outview dimensions & main parts of machine .....	2-10
2-5-1 Outvieww dimensions .....	2-10~2-15
2-5-2 Main parts of machine .....	2-16~2-19
2-6 Dimensions of working space .....	2-20
2-6-1 The interval of A.T.C and working .....	2-21~2-27
2-6-2 The interval of three axes .....	2-28~2-29
2-6-3 A.T.C travel .....	2-30~2-32
2-6-4 A.T.C travel ( have A.P.C ) .....	2-33~2-35

## CHAPTER 3 DESIGN AND FEATURES

3-1 Spindle.....	3-1
3-1-1 Tool shank and pull stud.....	3-2
3-1-2 Spindle output characteristic .....	3-3~3-10
3-2 Feed unit structure design .....	3-11
3-2-1 "X" axis.....	3-11
3-2-2 "Y" axis.....	3-12
3-2-3 "Z" axis.....	3-13
3-2-4 Table size & T slot dimensions.....	3-14~3-15
3-2-5 Guide ways.....	3-16
3-3 X,Y&Z travel orientation devices .....	3-17
3-3-1 "X" axis.....	3-17
3-3-2 "Y" axis.....	3-17
3-3-3 "Z" axis.....	3-18
3-4 A.T.C.....	3-19
3-4-1 A.T.C system.....	3-19
3-4-2 A.T.C cycle .....	3-20~3-27

## CHAPTER 4 PREPARATION BEFORE TRANSPORT AND INSTALLATION

4-1 Minimum space for foundation and maintenance.....	4-1
4-2 Power supplies .....	4-1
4-2-1 Electric.....	4-1
4-2-2 Grounding.....	4-1
4-2-3 Air .....	4-1
4-2-4 Cutting fluid.....	4-1
4-2-5 Hydraulic (30T) .....	4-2
4-3 Installation environment.....	4-3~4-4

## CHAPTER 5 TRANSPORT AND INSTALLATION

5-1 Packing .....	5-1
5-2 Safety precautions.....	5-1
5-3 Machine lifting.....	5-2~5-5
5-4 Temporary storage .....	5-6
5-5 Machine installation .....	5-6~5-10
5-6 Installation of chip conveyor .....	5-11
5-7 Intallation process for A.P.C .....	5-12~5-14

## CHAPTER 6 PREPARATION BEFORE MACHINE TRIAL RUN

6-1 The lifting jigs and fixtures removing .....	6-1
6-2 Cleaning machine .....	6-1
6-3 Leveling machine.....	6-2~6-3
6-4 Checking before operation.....	6-3
6-5 Warming up of spindle .....	6-4

**CHAPTER 7 MACHINE MAINTENANCE**

7-1 Arrangement of equipments .....7-1  
 7-2 Maintenance area ..... 7-2~7-4  
 7-3 The usual maintenance ..... 7-5~7-6  
 7-4 Mechanical cautions ..... 7-7~7-9  
 7-4-1 Preparing for operation..... 7-10~7-11  
 7-4-2 Precautions regarding safety.....7-12  
 7-5 Pneumatic and hydraulic system.....7-13  
 7-5-1 Pneumatic unit..... 7-13~7-16  
 7-5-2 Hydraulic unit..... 7-17~7-18  
 7-5-3 Pneumatic hydraulic maintenance seal..... 7-19~7-22  
 7-6 Control valves and limit switches..... 7-23~7-28  
 7-6-1 Additional information to be given on components..... 7-29~7-31  
 7-7 Troubles and remedies .....7-32  
 7-7-1 Troubles shooting .....7-32  
 7-8 Machine lubrication.....7-33  
 7-8-1 Lub. of guideways.....7-34  
 7-8-2 Lub. of spindle bearings ..... 7-34~7-35  
 7-8-4 Maintenance of electric intermittent pump..... 7-35~7-36  
 7-8-5 Lubrication system draw.....7-37  
 7-9 Adjustment of tapered gibs .....7-38  
 7-10 Tension adjustment of the spindle drive belt ..... 7-39~7-40

**CHAPTER 8 PARTS LIST**

8-1 Part assemblies check list ..... 8-1~8-2  
 8-2 Lists and drawing ..... A-1~J-4