

# HERBERT

## No.5 SENIOR PREOPTIVE MONOSLIDE LATHE

### OPERATORS HANDBOOK

FIRST EDITION

ALFRED

**HERBERT**

LTD., COVENTRY



**CONTENTS**

	<u>Page No.</u>
Machine specification ...	5
SECTION ONE - INSTALLATION	
Cleaning ...	9
Compressed air supply ...	11
Electrical connection ...	11
Electrically-operated jaw chuck ...	11
Electrically-operated toggle chuck and bar feed unit ...	11
Levelling ...	9
Slinging ...	9
SECTION TWO - LUBRICATION	
Air-operated jaw chuck ...	19
Electrically-operated jaw chuck ...	18
Electrically-operated toggle chuck ...	19
Feed box ...	18
Headstock ...	17
Lubricar ...	19
Lubricating oil ...	16
Monoslide ...	18
Motor drive ...	17
Saddle ...	18
SECTION THREE - SETTING, OPERATION AND DESCRIPTION	
Air-operated 3-jaw chuck ...	30
Bar feed units, hand and electrically operated ...	40
Chasing attachment ...	47
Chip guards, sliding ...	30
Chiprupter ...	44
Chucks	
-- air-operated jaw chuck ...	30
-- electrically-operated jaw chuck ...	34
-- hand and electrically-operated toggle chucks ...	37
Copying attachment ...	51
Electrically-operated 3-jaw chuck ...	34
Feed box ...	42
Leader control ...	53
Monoslide	
-- leader control ...	53
Motor drive ...	24
Overhead support ...	29
Preoptive headstock ...	25
Saddle, traversing ...	44
Spindle, main ...	29
Spindle speed	
-- pre-selection ...	27
-- changing ...	28
Taper-turning attachment ...	49

# CONTENTS

3

	Page No.
Toggle chuck, hand and electrically-operated	37
Tooling	55
-- standard outfits	55
Turret, square	46
SECTION 4 - COOLANT	
Cutting fluids	60
Turret internal coolant supply	59
SECTION 5 - MAINTENANCE AND DISMANTLING	
Chasing attachment	80
Chucks	
air-operated jaw chuck	70
-- chuck removal	71
-- chuck dismantling	71
-- cylinder dismantling	71
-- assembly on machine	71
electrically-operated jaw chuck	
-- chuck removal	71
-- chuck dismantling	71
-- power unit removal and dismantling	73
-- assembly on machine	74
electrically-operated toggle chuck	
-- removal and dismantling	75
Control gear	84
Electrical equipment	84
Feed box removal	78
Headstock	
-- oil filters	65
-- oil pump	65
-- oil pump removal	77
-- clutch adjustment	65
-- clutch plate renewal	76
-- main spindle bearing	69
-- main spindle bearing renewal	77
-- Preoptive motor removal	77
-- wormwheel renewal	77
Main motor	84
Monoslide	
-- removal	83
-- apron removal	83
-- apron dismantling	83
Motor drive	65
Saddle	
-- apron removal	78
-- wormwheel renewal	78
-- complete dismantling	79
-- cross slide screw and nut renewal	80
-- chasing friction device fitting	82
-- fitting bed wipers	83