


# Installation Manual

## ToPs Programming Systems

Version 3.1

**TRUMPF**



**Installation manual**

# **ToPs Programming Systems**

Version 3.1

Edition: **06/2004**



# Table of contents

<b>1.</b>	<b>Overview .....</b>	<b>8</b>
1.1	ToPs as a single workstation .....	8
1.2	ToPs as client/server system (optional) .....	8
<b>2.</b>	<b>Prerequisites .....</b>	<b>10</b>
2.1	General information.....	10
2.2	Hardware and operating system .....	11
	ToPs client and single workstation .....	11
	ToPs server.....	11
<b>3.</b>	<b>System components .....</b>	<b>12</b>
3.1	ToPs in general .....	12
	ToPsCopy .....	12
	Adobe Reader .....	13
	Niknak .....	13
	ODBC driver.....	13
	Dongle driver.....	14
	GeoViewer .....	14
	CAD-Converter .....	14
	NC-Link .....	15
	WZG-Export .....	15
3.2	ToPs server .....	15
	MSSQL server tools.....	15
	MS SQL (MSDE).....	16
	MS SQL-DB .....	16
	ToPsNet .....	19
	Dongle server.....	19
	Dongle monitor.....	21
<b>4.</b>	<b>Installing ToPs as a single workstation.....</b>	<b>22</b>
4.1	ToPs CAD, 100 lite, 300, 400, 2000 .....	22
	New installation .....	24
	Update.....	26
	Single functions.....	28
	Entering passwords .....	29
4.2	ToPs 600 and ToPs 800 .....	30
	New installation .....	31
	Update (only ToPs 600) .....	32
<b>5.</b>	<b>Installing ToPs as a client/server system.....</b>	<b>33</b>
5.1	Prior to the installation.....	33
	General preparations .....	33
	Selecting a configuration.....	34
	Selecting the installation type .....	36



5.2	Initial installation .....	37
	Flow chart.....	37
	Overview of the procedure.....	37
5.3	Extension to a client/server system .....	38
	Flow chart.....	38
	Overview of the procedure.....	39
5.4	Update.....	40
	Flow chart.....	40
	Overview of the procedure.....	40
5.5	Installation .....	41
	Install the ToPs server .....	41
	Setting up a file server .....	42
	Carry out a server database update .....	43
	Install/update the ToPs client.....	44
	Setting up a "TOPS" user group .....	48
<b>6.</b>	<b>Miscellaneous.....</b>	<b>49</b>
6.1	Installing ToPs 100 lite and ToPs 2000 at the machine.....	49
	Installation software .....	49
	Installation on 16-bit control systems.....	51
	Installation on 32-bit control systems.....	51
	Updating the database at the control system .....	52
6.2	Change operating system (ToPs single working station).....	53
6.3	Change computer (ToPs single working station) .....	53
	Without adopting data .....	53
	With data adoption .....	54
6.4	Editing machines and lasers (ToPs server) .....	55
6.5	Backing up the SQL database (ToPs server) .....	58
6.6	Administering licenses (ToPs server) .....	62
	Displaying existing licenses .....	62
	Installing new licenses .....	64
	Slot occupation .....	65