MAINTENANCE MANUAL

VERTICAL MACHINING CENTER

FNC128-A

(Spindle Head of 8000 rpm)

MAKINO MILLING MACHINE CO., LTD.

SPINDLE HEAD

7FN 10A

CONTENTS

	Page
1. INTRODUCTION	A - 1
2. SPINDLE DRIVE MECHANISM	A - 2
2.1 Gear Change and Shifter	A - 5
(1) Mechanism	A - 5
(2) Gear combinations in speed ranges	A - 7
2.2 Hydraulic Circuit for Shifter	A - 8
2.3 Limit Switches for Shifter	A -10
(1) Mounting positions	A -10
(2) Mounting construction and adjustment	A -11
3. SPINDLE MOTOR	A -13
3.1 Specifications	A -13
3.2 Maintenance	A -13
3.3 Troubleshooting	A -14
4. SPINDLE ORIENTATION MECHANISM	A -16
4.1 Composition	A -16
4.2 Polarity of Magnetic Material	A -17
4.3 Adjustment of Spindle Stop Angle	A -18
5. TOOL CLAMP MECHANISM	A -19
5.1 Mechanism	A -19
5.2 Hydraulic Circuit	A -19
5.3 D Air Venting	A -22
5.4 Limit Switches	A -23
(1) Mounting position	A -23
(2) Mounting construction and adjustment	A -24

6. Cleaning unit for spindle teper section ..... A -26
6.1 Composition ..... A -26
6.2 Function of Each Unit ..... A -28
6.3 Components of Each Unit ..... A -29
6.4 Adjustment ..... A -31
(1) Adjusting the pressure ..... A -31
(2) Adjusting the oil dropping rate and adding oil ..... A -31
6.5 Check ..... A -32
6.6 Disassembly ..... A -32
7. DISASSEMBLY AND ASSEMBLY OF MAIN PARTS ..... A -37
7.1 Tool Clamp Mechanism ..... A -37
(1) Cylinder ..... A -37
(2) Collet ..... A -37
7.2 Shifter ..... A -41
7.3 Intermediate Shaft ..... A -44
7.4 First Axis ..... A -44
7.5 Spindle ..... A -46

FEED MECHANISM

7FN 20A

CONTENTS

	Page
1. INTRODUCTION	B - 1
2. FEED DRIVE MECHANISM	B - 2
2.1 Composition	B - 2
2.2 Mechanism	B - 3
2.3 Pre-load of Ball Screw	B - 5
3. GIB MOUNTING POSITION AND ADJUSTMENT	B - 7
3.1 X Axis (FNC-128)	B - 7
3.2 X Axis (FNC-178, FNC-208)	B - 8
3.3 Y Axis (FNC-128)	B - 9
3.4 Y Axis (FNC-178, FNC-208)	B -10
3.5 Z Axis	B -11
4. BACKLASH COMPENSATION	B -12
4.1 Principle	B -12
4.2 Backlash Measurement	B -13
4.3 Removing the Backlash	B -14
5. PITCH ERROR COMPENSATING FUNCTION	B -15
6. MACHINE ZERO POINT AND MOVEMENT RANGE SETTING	B -16
6.1 Machine Zero Point	B -16
6.2 Zero Return	B -17
6.3 Movement Range Setting	B -18
7. FEED AXIS LIMIT SWITCHES	B -20
8. LUBRICATING UNIT	B -22
8.1 Specifications	B -22
8.2 Name of Each Part	B -23
8.3 Construction and Operating Principle	B -24
8.4 Delivery Rate	B -27
8.5 Replacement of Suction Filter	B -28
9. LUBRICATION OF X-AXIS BALL SCREW	B -29
10. REPLACEMENT OF FEED MOTOR CARBON BRUSH	B -30

AUTOMATIC TOOL CHANGER

1VN 120A

CONTENTS

	Page
1. INTRODUCTION	C - 1
2. MECHANISM AND ADJUSTMENT	C - 2
2.1 Arm-IN-OUT	C - 2
2.2 Arm Swing	C - 2
2.3 Arm Gripper Lock	C - 3
2.4 Index of Tool Magazine	C - 4
2.5 Swing of Tool Pot	C - 4
2.6 Tool Clamp-Unclamp in Pot	C - 5
2.7 Adjustment of Positions of Gripper and Spindle	C - 6
3. HYDRAULIC CIRCUIT	C -16
4. FIXED TERMINAL BLOCK AND SOLENOID VALVES	C -17
5. ATC SEQUENCE	C -18

HYDRAULIC UNIT

1VN 130A

CONTENTS

Page

1. INTRODUCTION ..... D - 1
2. HYDRAULIC CIRCUIT AND MAIN COMPONENTS ..... D - 2
3. MOUNTING POSITION OF MAIN COMPONENTS ..... D - 4
4. MAINTENANCE ..... D - 5
   4.1 Daily Maintenance ..... D - 5
   4.2 Periodic Maintenance ..... D - 6
      (1) Replacing the hydraulic oil ..... D - 6
      (2) Cleaning the reservoir ..... D - 7
5. FUNCTIONS AND CONSTRUCTIONS OF MAIN COMPONENTS ..... D - 8
   5.1 Motor Pump ..... D - 8
      (1) Construction ..... D - 8
      (2) Operation of pressure compensator ..... D -10
      (3) Adjusting method ..... D -12
      (4) Disassembling ..... D -13
      (5) Inspection of parts ..... D -16
      (6) Assembling ..... D -17
   5.2 Filter ..... D -21
      (1) Construction ..... D -21
      (2) Cleaning and replacing the element ..... D -24
   5.3 Solenoid Valve K-DSG-01-3C4-D24 (Yuken Kogyo) ..... D -26
   5.4 Oil Supply Port Breather UC-AB-1163-40 (Yuken Kogyo) ..... D -28
   5.5 Fixed Terminal Board TBD-10P (Todensha) ..... D -28
6. TROUBLESHOOTING ..... D -29
   6.1 Problem 1 ..... D -29
   6.2 Problem 2 ..... D -30
   6.3 Problem 3 ..... D -31

SPINDLE TEMPERATURE CONTROLLER

1VNE 3B

CONTENTS

		Page
1.	INTRODUCTION	E - 1
2.	SPECIFICATIONS	E - 2
3.	OPERATING PRINCIPLE	E - 4
4.	ELECTRIC CIRCUIT	E - 6
5.	CLEANING OF CONDENSER	E - 8
6.	TROUBLESHOOTING	E - 9
7.	LINE FILTER	E -12
	7.1 Construction	E -12
	7.2 Cleaning the Filter	E -13