

BED-TYPE CNC MILLING MACHINE

BMC 64

(FANUC SYSTEM OM/OM MATE)

Instruction Manual



LEBLOND MAKINO
ASIA PTE. LTD

2, Gul Avenue, Jurong Town, Singapore 2262,
Republic of Singapore
Tel: 8615722 Fax: 8611600
Telex: LEBASIA RS 24257

BED-TYPE CNC MILLING MACHINE

Instruction Manual

BMC 64

(FANUC SYSTEM OM/OM MATE)



LEBLOND MAKINO
ASIA PTE.LTD

2, Gul Avenue, Jurong Town, Singapore 2262,
Republic of Singapore
Tel: 8615722 Fax: 8611600
Telex: LEBASIA RS 24257

V9025E

1.	SPECIFICATION	1
1.1	Introduction	1
1.2	Name and Outline of Each Part	2
1.3	Main Dimension and values	5
1.4	Arrangement Diagram	6
1.5	Machine Zero Point Diagram	9
1.6	Numerical Control Unit (Fanuc System OM/OM Mate)	10
1.7	Standard Accessories	21
2.	INSTALLATION	24
2.1	Hoisting and transportation of the machine	24
2.2	Foundation	25
2.3	Installation	25
2.4	Removal of Rust Preventive	28
2.5	Removal of Clamp Fixtures	28
2.6	A Lubricant Supply	31
2.7	Oil Supply to Hydraulic Tank	33
2.8	Preparations for Operations	34
2.9	Oil Supply to Oilmatic	37
3.	OPERATING COMPONENTS	38
3.1	Machine Proper	38
4.	OPERATIONS	54
4.1	Manual Operations	54
4.2	Automatic Operations	60
5.	PROGRAMMING	66
5.1	M Function (Miscellaneous Function)	66
6.	CHECKS AT BEGINING OF DAILY WORK	69
6.1	Lubricant Tank	69
6.2	Automatic Spindle Temperature	69
6.3	Hydraulic Tank	69
6.4	ATC Unit	69
6.5	Emergency Stop Button	69
6.6	Reference Point Return	70
6.7	Others	70
7.	RUNNING-IN	70
7.1	Running-in of Spindle	70
7.2	Running-in of Axis	71

8.	PRECAUTIONS	71
	OPTIONS FOR CM	72
1.	Fanuc Cassette F1	72
2.	Fanuc PPR	73
3.	Conversational Programming with Graphic Function	74
4.	Menu Programming	75
5.	Tool Offset No. 64/99	76
6.	Jog Override	76
7.	Play Back	76
8.	Software Operator's Panel	77
9.	Run Time and Parts Count Display	78
10.	Pattern Data Input	79
11.	Custom Macro	80
12.	Tool Length Measurement	81
13.	External Data Input	82
	13.1 External Tool Compensation	82
14.	External Message Function	83
15.	External Key-Input Function	84
16.	Chinese Display	84
17.	Helical Interpolating	84
18.	Changing of Tool Offset Amount	84
19.	Program Restart	84
	OILMATIC	85
1.	Oilmatic Specification	86
2.	Circuit Coolant and Oil	87
3.	Electrical Circuit and Part List	88