

# OPERATING MANUAL

for

## QUICK TURN NEXUS 100/150

MANUAL No. : H311SG0014E

Serial No. :

*Before using this machine and equipment, fully understand the contents of this manual to ensure proper operation. Should any questions arise, please ask the nearest Technical/Service Center.*

### IMPORTANT NOTICE

1. Be sure to observe the safety precautions described in this manual and the contents of the safety plates on the machine and equipment. Failure may cause serious personal injury or material damage. Please replace any missing safety plates as soon as possible.
2. No modifications are to be performed that will affect operation safety. If such modifications are required, please contact the nearest Technical/Service Center.
3. For the purpose of explaining the operation of the machine and equipment, some illustrations may not include safety features such as covers, doors, etc. Before operation, make sure all such items are in place.
4. This manual was considered complete and accurate at the time of publication, however, due to our desire to constantly improve the quality and specification of all our products, it is subject to change or modification. If you have any questions, please contact the nearest Technical/Service Center.
5. Always keep this manual near the machinery for immediate use.
6. If a new manual is required, please order from the nearest Technical/Service Center with the manual No. or the machine name, serial No. and manual name.

Issued by *Manual Publication Section, Yamazaki Mazak Corporation, Japan*

# CONSTRUCTION

## Part 1 PRELIMINARIES TO MACHINE OPERATION

- Chapter 1 INTRODUCTION
- Chapter 2 SAFETY PRECAUTIONS

## Part 2 MACHINE OPERATION

- Chapter 1 MACHINE OVERVIEW
- Chapter 2 OPERATING PANEL AND FUNCTIONS OF SWITCHES
- Chapter 3 PREPARATION FOR OPERATION
- Chapter 4 MANUAL OPERATION
- Chapter 5 PREPARATION FOR MACHINING

## Part 3 OPERATING NC UNIT AND PREPARATION FOR AUTOMATIC OPERATION

- Chapter 1 PREPARATION FOR AUTOMATIC OPERATION
- Chapter 2 DISPLAY OVERVIEW
- Chapter 3 DATA SETTING METHODS
- Chapter 4 DISPLAYS RELATED TO THE MACHINE OPERATIONAL STATUS
- Chapter 5 DISPLAYS RELATED TO MACHINING SET UP
- Chapter 6 DISPLAYS RELATED TO PROGRAM CREATION
- Chapter 7 DISPLAYS RELATED TO TOOLS
- Chapter 8 DISPLAYS RELATED TO PARAMETERS
- Chapter 9 DISPLAY RELATED TO DATA STORAGE
- Chapter 10 DISPLAYS RELATED TO DIAGNOSIS

## Part 4 AUTOMATIC OPERATION

- Chapter 1 AUTOMATIC OPERATION EXECUTION
- Chapter 2 SELECTING EXECUTION CONDITIONS
- Chapter 3 CHANGING THE CUTTING CONDITIONS
- Chapter 4 STOPPING AUTOMATIC OPERATION
- Chapter 5 MANUAL INTERRUPTION
- Chapter 6 OPERATIONS POSSIBLE DURING AUTOMATIC OPERATION
- Chapter 7 COMPLETION OF OPERATION

## Part 5 APPENDIX

- Chapter 1 STANDARD SPECIFICATION OF THE MACHINE
- Chapter 2 M-CODE LIST
- Chapter 3 ALARM LIST