

INSTRUCTION MANUAL SG M-S

INJECTION MOLDING MACHINE

**SG50•75•100•125•
180•260•350**

 **Sumitomo Heavy Industries, Ltd.**

'97.12. 2nd Ed

Table of Contents

INTRODUCTION	Introduction	
Chapter 1 SUMMARY	Main Specifications 1 - 1 Identification of Molding Machine Components 1 - 3 Operation Panel Identification 1 - 4 Arrangement of Encoders/Limit Switches/Proximity Switches 1 - 5	
Chapter 2 PREPARATION FOR OPERATION	For Your Safety 2 - 1 Preparation and Checking before Operation 2 - 2 1. Charging the Accumulator with Nitrogen Gas 2 - 4 2. Checking the Hydraulic Tank and Lubricating Oil Tank for Proper Oil Level 2 - 7 3. Feeding the Hydraulic Oil Cooling Water 2 - 7 4. Feeding of Water to Water Jacket 2 - 8 5. Resetting the Emergency Stop Button 2 - 9 6. Main Power Supply and Control Power Supply 2 - 9 7, 8. Hydraulic Oil Pump Motor ON/OFF 2 - 10 9. Supplying the Heater Power/Heating up the Heating Cylinder 2 - 11 10. Air Bleeding from Hydraulic System 2 - 12 11. Mold Clamping Safety System (Safety door interlocking function) 2 - 13 12. Injection Unit Safety Device 2 - 15	
Chapter 3 OPERATION	Effects of Mode Selection 3 - 1 Starting of Motor and Heater 3 - 2 Operations in Standby Mode 3 - 3 Operations in Manual Mode 3 - 5 Operation in OFF Mode 3 - 9 Operations in Semi-Automatic Mode 3 - 10 Operations in Automatic Mode 3 - 12	

**Chapter 4
MOLDING
PROGRAM
(SGM-S)**

Operation/Programming Panel Identification	4 - 1
Various LEDs / Space Card Slot	4 - 2
Emergency Stop Button & Display	4 - 3
Identificatin of Screen Setting Keys	4 - 4
Programming Method	4 - 5
Examples of Displayed Screen	4 - 7
SET UP Screen	4 - 22
STANDBY Screen	4 - 25
CLAMP Screen	4 - 27
EJECTOR Screen	4 - 31
INJECTION Screen	4 - 34
INJECTION Screen (2V- 2P)	4 - 37
INJECTION Screen (5V-4P)	4 - 39
INJ. DETAIL Screen	4 - 41
TEMP. Screen	4 - 43
TEMP: MOLD Screen	4 - 47
CUTOUT Screen	4 - 48
OUTLINE Screen (2V-2P)	4 - 51
OUTLINE Screen (5V-4P)	4 - 52
ANALYSIS Screen	4 - 53
SUPERVI. Screen	4 - 55
Q' LTY CONT Screen	4 - 59
Q' : DETAIL Screen	4 - 62
PROD CONT Screen	4 - 64
STOKER Screen	4 - 66
STORAGE Screen	4 - 67
AUTO PROG. Screen	4 - 69
SET. LIST Screen	4 - 71
AUTO START Screen	4 - 73
MAINT Screen	4 - 75
ABNORMAL Screen	4 - 77
SYSTEM Screen	4 - 86
I/O CHECK Screen	4 - 89

**Chapter 5
MOLDING**

Checking before Operation/Starting	5 - 1
Mounting the Mold	5 - 4
Symptoms and Causes of Main Molding Defects	5 - 20
Checking at the End of Molding Operation/Stopping the Machine	5 - 21

Chapter 6 FUNCTION OF INDIVIDUAL UNITS	Hydraulics 6 – 1 Mold-Clamping Unit 6 – 2 Hydraulic Ejector (b) 6 – 6 Mold-Clamping Force Adjuster 6 – 8 Central Lubricating System 6 – 9 Takeout Robot Connector 6 – 10 Injection and Plasticizing Unit (S Type) 6 – 14 SGM-S Control System 6 – 21 Basic Principle of Closed-loop Control 6 – 23
Chapter 7 MAINTENANCE	Daily Inspection 7 – 1 Every Month Inspection 7 – 18 Every 3 Months Inspection 7 – 22 Every 6 Months Inspection 7 – 28 Every Year Inspection 7 – 35 Disassembling and Reassembling Screw Assembly 7 – 42 Nozzle Center Adjustment 7 – 53 Replacing the Fuses 7 – 55 Replacing the Battery 7 – 60
Chapter 8 OPTIONAL ACCESSORIES	The following provides useful data well fitted to customer's specification
APPENDIX	Selection of an Injection Molding Machine A – 1 Making a Choice of Screw Assembly A – 3 Characteristics of Thermoplastic Resin & General Molding Conditions A – 6 How to Calculate Plasticizing Stroke A – 8 How to Calculate Mold Clamping Force A – 9 Consideration to be Given to Purging A – 10
Guide to Preparations for Installation	Read this Instruction Guide before operating your machine
ATTACHED MATERIALS	General Assembly Foundation Plan Mold Platens Nozzle • Needle • Heater List Hopper Arrangement Hydraulic Diagram Operational Sequence Locations of Hydraulic Components Mold-clamping Cylinder Hydraulic Ejector Cylinder Injection Unit Nozzle-closing Cylinder Control Unit Parts Layout MMC Unit Parts Layout Elementary Diagram Heater Bands Spare Parts List Parts Guide