

INSTRUCTION MANUAL
SINKER EDM
MGH~MGH5 GENERATOR

ALARM MESSAGE
(ALARM, WARNING, GUIDE)



7GF1-ND04-0703(E)

CONTENTS

1. COMMENT OF DESCRIPTION	1-1
1.1 Trouble Remedy List	1-2
1.2 Resetting Method.....	1-2
1.3 Dialog Box	1-3
1.4 Alarm Numbers	1-3
1.5 Confirming Name of Trouble	1-4
1.6 Confirming Troubling Process Conditions	1-4
1.7 Level display of LF and BF key	1-4
 2. DESCRIPTION OF MESSAGES.....	 2-1
2.1 The message of 0001 to 0999.....	2-1-1
2.2 The message of 1000 to 1999.....	2-2-1
2.3 The message of 2000 to 2999.....	2-3-1
2.4 The message of 3000 to 3999.....	2-4-1
2.5 The message of 4000 to 4999.....	2-5-1
2.6 The message of 5000 to 5999.....	2-6-1
2.7 The message of 6000 to 6999.....	2-7-1
2.8 The message of 7000 to 7999.....	2-8-1
2.9 The message of 10000 to	2-9-1