

Programmable Controllers

C200HX-CPU□□-ZE

C200HG-CPU□□-ZE

C200HE-CPU□□-ZE

OPERATION MANUAL

OMRON

C200HX-CPU□□-ZE

C200HG-CPU□□-ZE

C200HE-CPU□□-ZE

Programmable Controllers

Operation Manual

Produced August 1997

TABLE OF CONTENTS

PRECAUTIONS	xiii
1 Intended Audience	xiv
2 General Precautions	xiv
3 Safety Precautions	xiv
4 Operating Environment Precautions	xiv
5 Application Precautions	xv
6 Conformance to EC Directives	xvi
SECTION 1	
Introduction	1
1-1 Overview	2
1-2 The Origins of PC Logic	2
1-3 PC Terminology	3
1-4 OMRON Product Terminology	4
1-5 Overview of PC Operation	4
1-6 Peripheral Devices	5
1-7 Available Manuals	6
1-8 C200HX/HG/HE Features	7
SECTION 2	
Hardware Considerations	13
2-1 CPU Unit Components	14
2-2 PC Configuration	17
2-3 CPU Unit Capabilities	17
2-4 Memory Cassettes	18
2-5 Operating without a Backup Battery	21
2-6 CPU Unit DIP Switch	22
SECTION 3	
Memory Areas	23
3-1 Introduction	25
3-2 Data Area Structure	26
3-3 IR (Internal Relay) Area	30
3-4 SR (Special Relay) Area	33
3-5 AR (Auxiliary Relay) Area	50
3-6 DM (Data Memory) Area	57
3-7 HR (Holding Relay) Area	70
3-8 TC (Timer/Counter) Area	70
3-9 LR (Link Relay) Area	71
3-10 UM Area	71
3-11 TR (Temporary Relay) Area	72
3-12 EM (Extended Data Memory) Area	72

TABLE OF CONTENTS

SECTION 4

Writing and Inputting the Program	75
4-1 Basic Procedure	77
4-2 Instruction Terminology	77
4-3 Program Capacity	78
4-4 Basic Ladder Diagrams	78
4-5 The Programming Console	91
4-6 Preparation for Operation	94
4-7 Inputting, Modifying, and Checking the Program	107
4-8 Controlling Bit Status	123
4-9 Work Bits (Internal Relays)	125
4-10 Programming Precautions	127
4-11 Program Execution	129
4-12 Special I/O Unit Interface Programs	129
4-13 Analog Timer Unit Programming	133

SECTION 5

Instruction Set	139
5-1 Notation	143
5-2 Instruction Format	143
5-3 Data Areas, Definer Values, and Flags	143
5-4 Differentiated Instructions	145
5-5 Expansion Instructions	146
5-6 Coding Right-hand Instructions	147
5-7 Instruction Set Lists	150
5-8 Ladder Diagram Instructions	155
5-9 Bit Control Instructions	156
5-10 INTERLOCK and INTERLOCK CLEAR – IL(002) and ILC(003)	162
5-11 JUMP and JUMP END – JMP(004) and JME(005)	164
5-12 END – END(001)	165
5-13 NO OPERATION – NOP(000)	165
5-14 Timer and Counter Instructions	166
5-15 Data Shifting	177
5-16 Data Movement	186
5-17 Data Comparison	199
5-18 Data Conversion	214
5-19 Symbol Math Instructions	238
5-20 BCD Calculations	258
5-21 Binary Calculations	274
5-22 Special Math Instructions	288
5-23 Logic Instructions	305
5-24 Subroutines and Interrupt Control	309
5-25 Step Instructions	321
5-26 Special Instructions	330
5-27 Network Instructions	353
5-28 Serial Communications Instructions	359
5-29 Advanced I/O Instructions	366
5-30 Special I/O Unit Instructions	381

SECTION 6

Program Execution Timing	385
6-1 Cycle Time	386
6-2 Calculating Cycle Time	390
6-3 Instruction Execution Times	393
6-4 I/O Response Time	404

TABLE OF CONTENTS

SECTION 7

Program Monitoring and Execution 417

- 7-1 Monitoring Operation and Modifying Data 418
- 7-2 Programming Console Operations 418

SECTION 8

Serial Communications 445

- 8-1 Introduction 446
- 8-2 Host Link Communications 447
- 8-3 RS-232C Communications 454
- 8-4 One-to-one PC Links 458
- 8-5 NT Links 460
- 8-6 The Protocol Macro Function 461

SECTION 9

Troubleshooting 471

- 9-1 Alarm Indicators 472
- 9-2 Programmed Alarms and Error Messages 472
- 9-3 Reading and Clearing Errors and Messages 472
- 9-4 Error Messages 473
- 9-5 Error Flags 477
- 9-6 Host Link Errors 478

SECTION 10

Host Link Commands 481

- 10-1 Host Link Command Summary 482
- 10-2 Host Link End Codes 483
- 10-3 Host Link Commands 486

Appendices

- A Standard Models 529
- B Programming Instructions 545
- C Error and Arithmetic Flag Operation 555
- D Word Assignment Recording Sheets 561
- E Program Coding Sheet 567
- F Data Conversion Tables 569
- G Extended ASCII 571

Glossary 573