

# HERBERT No. 4 SENIOR CAPSTAN LATHES

(7 $\frac{3}{4}$ " CENTRES)

SPARE PARTS LIST FOR MACHINES WITH 7 $\frac{1}{8}$ " CENTRES ALSO AVAILABLE.

SPARE PARTS LIST

(1st Edition)



ALFRED HERBERT LTD., COVENTRY

# HERBERT No. 4 SENIOR CAPSTAN LATHES

(7 $\frac{3}{4}$ " CENTRES)

SPARE PARTS LIST FOR MACHINES WITH 7 $\frac{1}{8}$ " CENTRES ALSO AVAILABLE.

## IMPORTANT.

WHEN ORDERING SPARE PARTS IT IS ESSENTIAL TO QUOTE :—

1. **INSPECTION No. of the machine** for which the part is required. This is stamped on the top surface at the right-hand end of the bed of the machine. (See illustrations on Page 2).
2. **PHOTOGRAPH No.** of the part as indicated in this list. The photograph number is useless for identification unless the **INSPECTION NUMBER** is quoted as well.
3. **IF INSPECTION No. IS NOT AVAILABLE.** On older types of machines the Inspection No. may have been removed during re-conditioning ; if so, the type and size of the machine should be quoted and should be accompanied by a dimensional sketch of the part required or the damaged part itself should be sent to us.
4. **HOW MANY SIMILAR PARTS ARE REQUIRED ?**

THE ILLUSTRATIONS IN THIS LIST ARE NOT NECESSARILY CORRECT IN DETAIL OWING TO ALTERATIONS IN DESIGN, BUT IF THE ABOVE INFORMATION IS GIVEN THE CORRECT PART WILL BE SUPPLIED.

## INDEX

	Page		Page
Preoptive Headstock (Plates SP230, 231, 232, 233, 234 and 235 ... ..)	3-9	Bed (Plate SP255) ... ..	27 and 28
Dial Change Headstock (Plates SP236, 237, 238, 239, 240 and 241) ... ..	9-14	Motor Drive (Plate SP256) ... ..	29 and 30
Traversing Saddle (Plates SP242 and 243) ... ..	15-17	Pump and Chuck Guards (Plates SP257 and 258) ... ..	30 and 31
Traversing Saddle Apron (Plates SP244 and 245) ... ..	17-19	2" Capacity Hand-operated Dead-length Bar Chuck and Revolving Holder (Plate SP259) ... ..	32
Chasing Attachment (Plate SP246) ... ..	19 and 20	2" Capacity Hand and Electric Double-toggle Chucks (Plates SP260, 261 and 262) ... ..	33-35
Taper Turning Attachment (Plates SP247 and 248) ... ..	20-22	2" Capacity Hand and Power-operated Bar Feeds (Plate SP263) ... ..	35 and 36
Capstan Slide (Plates SP249 and 250) ... ..	22-24	2" Capacity Hand-operated Bar Feed (Plate SP264) ... ..	37
Capstan Slide Apron (Plates SP251 and 252) ... ..	24 and 25	2" Capacity Power-operated Bar Feed (Plates SP265 and 266) ... ..	38 and 39
Feed Box (Plates SP253 and 254) ... ..	26 and 27	Electrical Spares ... ..	40-48