





MAKINO

**INSTALLATION & INSTRUCTION
MANUAL (*MIMAX659201*)**

MAX 65

MAY 1996 VER 1.0
MI01, MAX 65

INSTALLATION & INSTRUCTION MANUAL (*MIMAX659201*)



MAX 65

VERTICAL MACHINING CENTRE MAX 65

INDEX

CHAPTER	DESCRIPTION	
A	SAFETY	A-1 to A-9
B	SPECIFICATION	B-1 to B-19
C	INSTALLATION	C-1 to C-29
D	POWER & CONTROL	D-1 to D-10
E	SPINDLE	E-1 to E-9
F	AUTOMATIC TOOL CHANGER	F-1 to F-19
G	TOOLING	G-1 to G-6

APPENDIX

1	AIR SUPPLY	H-1 to H-3
2	AUTOMATIC LUBRICATION UNIT	I-1 to I-2
3	SPINDLE TEMPERATURE CONTROLLER	J-1 to J-7
4	CONVERSION FACTOR	K-1 to K-8