



AIR REQUIREMENTS	(PER MACHINE)
MP OPERATING	80 PSI 10 CFH
MP START UP (AIR BAG)	80 PSI 500 CFH

[illegible]