

OSP-U100 OSP-U10

MAC MAN

INSTRUCTION MANUAL



Publication No. 4201-E

TABLE OF CONTENTS

	<u>PAGE</u>
SECTION 1 MACMAN	1
1. OVERVIEW	1
1-1. MacMan Provides the Live Production Status Information	1
1-2. MacMan Slashes Down Time	4
1-3. MacMan Streamlines In-process Setup Time	5
1-4. List of MacMan Operations	6
 SECTION 2 MACMAN MAIN SCREEN	 10
2-1. Machining Status	11
2-2. Today's Machining Report	12
2-3. Today's Operating Report	14
2-4. Changing the Reason of Not-operating Status	16
 SECTION 3 DOCUMENT DISPLAY	 20
 SECTION 4 MEMO DISPLAY	 22
4-1. Displaying a Memo File	23
4-2. Reading a Memo File	25
4-3. Selecting a File from Directory	28
 SECTION 5 JOB PROCEDURE DISPLAY	 32
5-1. Display a Job Procedure File	32
5-2. Reading a Job Procedure File	33
 SECTION 6 MACHINING PREPARATION	 34
6-1. Display of Operation Files and Preparation Files	35
6-2. Reading a Machining Program File	36

	<u>PAGE</u>
SECTION 7 REPORT INFORMATION DISPLAY	40
SECTION 8 MACHINING REPORT DISPLAY	46
8-1. Daily Machining Report (Today)	46
8-2. Daily Machining Report (Pre Day)	49
8-3. Period Machining Report	51
8-4. Outputting the Machining Report to Floppy Disk	53
8-5. Outputting the Machining Report to Printer	55
SECTION 9 OPERATING REPORT	56
9-1. Daily Operating Report (Daily)	56
9-2. Daily Operating Report (Pre Day)	58
9-3. Period Operating Report (To-Today)	60
9-4. Outputting the Operating Report to Floppy Disk	63
9-5. Outputting the Operating Report to Printer	64
SECTION 10 OPERATING HISTORY	65
10-1. Daily Operating History (Today)	65
10-2. Daily Operating History (Pre Day)	67
10-3. Outputting the Operating History to Floppy Disk	69
10-4. Outputting the Operating History to Printer	70
SECTION 11 TROUBLESHOOTING INFORMATION	71
SECTION 12 NC STATUS AT ALARM	75
12-1. Selecting the Alarm for Output	76
12-2. Outputting the NC Status at Alarm to Floppy Disk	77
12-3. Outputting the NC Status at Alarm to Printer	79
SECTION 13 CURRENT NC STATUS	80
13-1. Selecting the Output Data	81
13-2. List of Output Data	84

	<u>PAGE</u>
13-3. Outputting the Current NC Status to Floppy Disk	87
13-4. Outputting the Current NC Status to Printer	89
SECTION 14ALARM HISTORY	90
14-1. Displaying the Alarm History	91
14-2. Outputting the Alarm History to Floppy Disk	92
14-3. Outputting the Alarm History to Printer	94
SECTION 15OPERATION HISTORY	95
15-1. Operation History - Console Line	95
15-2. Operation History - Operation Panel	97
15-3. Operation History - I/O Signals	101
15-4. Outputting the Operation History to Floppy Disk	103
15-5. Outputting the Operation History to Printer	105
SECTION 16VARIABLE HISTORY	106
16-1. Displaying the Variable History	107
16-2. Outputting the Variables History to Floppy Disk	110
16-3. Outputting the Variables History to Printer	112
SECTION 17PREFERENCE SETTINGS	113
17-1. REPORT/PRINTER Screen	118
17-2. INPUT DATA Screen	121
17-3. OUTPUT DATA Screen	123
17-4. I/O Signals	127
17-5. VARIABLES-A Screen to VARIABLES-D Screen	130
SECTION 18LIST OF OUTPUT MESSAGES	133
SECTION 19OUTPUT FILES	137
