

PJ-A3000 Series

Measuring Projector

User's Manual

Read this User's Manual thoroughly
before operating the instrument. After reading,
retain it close at hand for future reference.

Mitutoyo

CONTENTS

Conventions Used in this User's Manual	i
Safety Precautions	i
On Various Types of Notes	v
Handling precautions	vi
Guarantee	vi
1. Overview	1-1
1.1 Outline	1-1
1.1.1 Name of Each Part	1-1
1.1.2 Control panel	1-2
1.1.3 Angle counter and X, Y counter	1-3
1.1.4 Power panel	1-4
2. Installation and Setup	2-1
2.1 Installation	2-1
2.1.1 Environmental Conditions	2-1
2.1.2 Transportation and installation	2-2
2.1.3 Setting up the main unit	2-3
2.1.4 Removing the carrying handles	2-3
2.2 Assembly	2-4
2.2.1 Installing the cross-travel stage and Digimatic Head (for PJ-A3005D-50)	2-4
2.2.2 Installing the cross-travel stage and connecting the Linear Scale cables (for PJ-A3010F-200)	2-7
2.2.3 Connecting the Optoeye A2 Image Edge Sensor (for PJ-3010F-200)	2-9
2.2.4 Mounting the projection lens	2-10
2.2.5 Setting the power voltage	2-10
2.2.6 Connecting the power cord	2-11
2.3 Initial Checks (Functional Check)	2-12
2.3.1 Electrical component connectors	2-12
2.3.2 Main switch (ON-OFF)	2-12
2.3.3 Switches for Contour illumination and reflected illumination	2-12
2.3.4 Focusing wheel	2-13
2.3.5 Cross-travel stage	2-13
2.3.6 Projection screen	2-13
2.3.7 Others	2-13
2.4 Initial Checks (Performance Check)	2-14
2.4.1 Checking the position of the contour illumination bulb filament	2-14
2.4.2 Checking the position of the surface illumination bulb filament	2-14
2.4.3 Projection with contour illumination	2-16
2.4.4 Projection with reflected illumination	2-17
2.4.5 Color fitter	2-18
2.4.6 Checking the magnification accuracy	2-19
2.4.7 Checking the cross-travel stage travel direction	2-21
2.4.8 Checking the cross-travel stage feed error	2-23
2.4.9 Checking the resolution (in contour illumination mode)	2-23

2.5	Adjustment	2-24
2.5.1	Adjusting the magnification	2-24
2.5.2	Aligning the cross-travel stage travel direction to the cross-hair lines	2-24
2.5.3	Centering the protractor screen	2-24
3.	Operation	3-1
3.1	Projection Lens Selection	3-1
3.1.1	Selecting the projection lens	3-1
3.1.2	Replacing the projection lens	3-2
3.2	Mounting the Workpiece	3-2
3.3	Focusing and Positioning the Workpiece	3-4
3.3.1	Focusing	3-4
3.3.2	Positioning the workpiece	3-5
3.4	Measurement and Inspection	3-6
3.4.1	Rectangular coordinate measurement (with the X, Y counter)	3-6
3.4.2	About parameters	3-9
3.4.3	Dimensional measurement using a scale	3-15
3.4.4	Comparison with an overlay chart	3-15
3.4.5	Angle measurement (Using the Angle counter)	3-16
4.	Troubleshooting	4-1
4.1	Main Unit	4-1
4.2	Counter Unit	4-2
4.3	Error Messages and Remedies	4-3
4.4	Others	4-3
4.4.1	Error is observed in glass scale or overlay chart measurement	4-3
4.4.2	Abnormal cross-travel stage operation, and measurement errors occur	4-3
4.4.3	Abnormal protractor screen operation	4-4
4.4.4	Partial obscured image	4-4
4.4.5	Digimatic Head Key Operation and Counter Display (for PJ-A3005D-50)	4-4
5.	Maintenance	5-1
5.1	Maintenance of Optical Components	5-1
5.1.1	Projection lens	5-1
5.1.2	Half-reflecting mirror for surface illuminator	5-1
5.1.3	Mirror(surface reflecting mirror)	5-1
5.1.4	Screen glass	5-1
5.2	Maintenance of Mechanical Components	5-2
5.2.1	Projector main unit	5-2
5.2.2	Cross-travel stage	5-2
5.3	Replacing Disposable Parts	5-3
5.3.1	Bulbs for contour and surface illuminators	5-3
5.3.2	Fuse	5-5
5.3.3	Stage glass	5-6
5.4	Periodic Inspection	5-6
5.5	List of Consumable	5-7

6. Specifications	6-1
6.1 General	6-1
6.1.1 Common Specifications	6-1
6.1.2 Individual specifications	6-3
6.1.3 Data output (RS232C)	6-4
6.1.4 Connector specifications	6-4
6.1.5 Data output operation	6-6
6.1.6 Connecting Micropak	6-9
6.1.7 Connecting QM-Data 200	6-10
6.1.8 Data output (SPC)	6-10
6.2 Performance Table for the PJ-A3000 Series Projectors	6-14
6.3 Optical Path	6-15
6.4 External dimensions	6-16
6.4.1 Main Unit	6-16
6.4.2 Cross-travel stage	6-19
6.5 Accessories	6-21
6.5.1 Standard accessories	6-21
6.5.2 Optional accessories	6-22

SERVICE NETWORK