

OPERATING MANUAL & MAINTENANCE MANUAL

GL 01 & GL 03

(QUICK TURN PRIMOS 50 S
QUICK TURN PRIMOS 100 S
QUICK TURN PRIMOS 150 S)

Manual No. : HG20SBS014E

Serial No. :

Before using this machine and equipment, fully understand the contents of this manual to ensure proper operation. Should any questions arise, please ask the nearest Technical Center or Technology Center.

IMPORTANT NOTICE

1. Be sure to observe the safety precautions described in this manual and the contents of the safety plates on the machine and equipment. Failure may cause serious personal injury or material damage. Please replace any missing safety plates as soon as possible.
2. No modifications are to be performed that will affect operation safety. If such modifications are required, please contact the nearest Technical Center or Technology Center.
3. For the purpose of explaining the operation of the machine and equipment, some illustrations may not include safety features such as covers, doors, etc. Before operation, make sure all such items are in place.
4. This manual was considered complete and accurate at the time of publication, however, due to our desire to constantly improve the quality and specification of all our products, it is subject to change or modification. If you have any questions, please contact the nearest Technical Center or Technology Center.
5. Always keep this manual near the machinery for immediate use.
6. If a new manual is required, please order from the nearest Technical Center or Technology Center with the manual No. or the machine name, serial No. and manual name.

Issued by Manual Publication Section, YAMAZAKI MAZAK CORPORATION, Japan

CONTENTS

PART 1 ABOUT THIS MANUAL

1. INTRODUCTION
2. SAFETY PRECAUTIONS

PART 2 SYSTEM OVERVIEW AND PREPARATION FOR OPERATION

1. OUTLINE OF MACHINE
2. PREPARATION FOR OPERATION

PART 3 HANDLING OF NC UNIT, REMOTE OPERATING BOX, AND MANUAL/AUTOMATIC OPERATION

1. OUTLINE OF DISPLAY SCREENS
2. JOG BOX
3. GL SCREEN
4. MANUAL OPERATION
5. GANTRY LOADER SETUP PROCEDURE
6. STOPPING THE ROBOT
7. EASY RECOVERY FUNCTION

PART 4 MAINTENANCE

1. REGULAR MAINTENANCE AND INSPECTION
2. MAINTENANCE OF MAJOR UNITS
3. INSTALLATION
4. TROUBLESHOOTING

PART 5 APPENDIX

1. SPECIFICATION LIST
2. RESTRICTIONS ON WORKPIECE SHAPE
3. PNEUMATIC CIRCUIT
4. ALARM TABLES
5. M CODE TABLES
6. PARAMETER TABLES
7. BARRIER
8. MACHINE TRANSPORT

PART 1

ABOUT THIS MANUAL

CONTENTS

1	INTRODUCTION	1-1
1-1	Machine Overview	1-1
1-1-1	Purpose.....	1-1
1-1-2	Operating position	1-1
1-1-3	Features.....	1-2
1-2	List of Manuals to Be Used.....	1-3
1-3	Numbering System for Pages.....	1-3
1-4	Numbering System for Figures and Tables	1-3
2	SAFETY PRECAUTIONS.....	2-1
2-1	Rule	2-1
2-2	Basic Safety	2-1
2-3	Clothing and Personal Safety	2-3
2-4	Safety Items Related to Operation	2-3
2-5	Safety Items Related to Holding Workpieces	2-3
2-6	Safety Items Related to Maintenance.....	2-4
2-7	Precautions on Equipment Surroundings	2-4
2-8	Safety Items Related to Safety Devices	2-4
2-9	Safety Devices	2-5

PART 2

SYSTEM OVERVIEW AND
PREPARATION FOR OPERATION

CONTENTS

1	OUTLINE OF MACHINE.....	1-1
1-1	General.....	1-1
1-2	Configuration.....	1-2
1-2-1	Main GL unit.....	1-4
1-2-2	Traverse axis (B-axis).....	1-5
1-2-3	Vertical axis (A-axis).....	1-6
1-2-4	Hand section.....	1-7
1-2-5	Rotary conveyor (10 pallets).....	1-28
1-3	Outline of Machine Control.....	1-35
1-4	Arrangement of Proximity Switch and Solenoid Valve (STD).....	1-36
2	PREPARATION FOR OPERATION.....	2-1
2-1	Checkups before Starting Operation.....	2-1
2-2	Stopping the GL.....	2-1
2-2-1	Emergency stop.....	2-1
2-2-2	Stopping the GL in other cases.....	2-1
2-3	Switching the Power ON.....	2-2
2-4	Checkups after Switching Power ON.....	2-2
2-5	Switching the Power OFF.....	2-3

PART 3

HANDLING OF NC UNIT,
REMOTE OPERATING BOX, AND
MANUAL/AUTOMATIC OPERATION

CONTENTS

1	OUTLINE OF DISPLAY SCREENS.....	1-1
1-1	CNC (Lathe) Screen and Gantry Loader (GL) Screen.....	1-1
1-1-1	Switching from the CNC (Lathe) screen mode to GL screen mode.....	1-1
1-1-2	Switching from the GL screen mode to the CNC (Lathe) screen mode.....	1-1
1-2	GL POSITION Screen	1-2
1-3	GL CUSTOM MACRO Screen	1-4
1-3-1	Displaying and setting custom macro common variable	1-4
1-3-2	Description for each custom macro	1-5
1-3-3	Navigation.....	1-5
1-4	GL PROGRAM Screen.....	1-6
1-5	GL MESSAGE Screen.....	1-7
1-5-1	Alarm and operator's message screen.....	1-7
1-5-2	GL ALARM HISTORY screen.....	1-8
2	JOG BOX	2-1
3	GL SCREEN.....	3-1
3-1	Displaying the GL Screen.....	3-1
3-2	Layout of NC Screen and MDI Panel.....	3-2
3-3	Operating Panel and Functions of Switches.....	3-3
3-4	Indicator Lamps on the Operating Panel	3-6
3-5	GL Operating Panel (Integrated with Lathe Panel).....	3-7
3-6	GL Machine Menu	3-9
3-6-1	Description of GL machine menu	3-10

4	MANUAL OPERATION.....	4-1
4-1	Axis Feed Operations (Vertical Axis (A-axis) and Traverse Axis (B-axis)).....	4-1
4-1-1	Jog feed	4-1
4-2	GL Hand Operation	4-2
4-2-1	Rotation of the GL hand	4-2
4-2-2	Opening and closing the GL hands	4-3
4-2-3	OD (external) gripping and ID (internal) gripping	4-4
4-2-4	Hand air blow operation	4-5
4-3	Rotary Conveyor Operation.....	4-6
4-3-1	Operation panel for rotary conveyor	4-6
4-3-2	Adjusting the guide bar.....	4-8
4-3-3	Preparation for automatic operation of rotary conveyor	4-9
5	GANTRY LOADER SETUP PROCEDURE	5-1
5-1	Method 1	5-1
5-2	Method 2	5-14
6	STOPPING THE ROBOT	6-1
6-1	Methods of Stopping the Robot.....	6-1
6-1-1	Emergency stop	6-1
6-1-2	Stop caused by pressing the RESET key.....	6-2
6-1-3	Feed hold.....	6-3
6-1-4	Stop caused by turning off the power	6-3
6-2	Cleaning and Inspection after Finishing Operation.....	6-4
7	EASY RECOVERY FUNCTION.....	7-1

7-1 Condition of Recovery Function7-1

PART 4

MAINTENANCE

CONTENTS

1	REGULAR MAINTENANCE AND INSPECTION	1-1
1-1	General.....	1-1
1-2	Maintenance Cover	1-2
1-3	Tables of Regular Maintenance and Inspection Items.....	1-3
1-4	Lubrication.....	1-4
1-4-1	Grease lubrication locations	1-5
1-4-2	LM guide rail E2 system	1-6
1-4-3	LM guides lubrication (E2 system from HIWIN)	1-7
2	MAINTENANCE OF MAJOR UNITS.....	2-1
2-1	Hand Section.....	2-1
2-1-1	Hand adjustment	2-1
2-2	Workpiece Conveyor	2-2
2-2-1	General view of conveyor.....	2-3
2-2-2	Conveyor chain tension adjustment.....	2-4
3	INSTALLATION	3-1
3-1	Preparation for Installation.....	3-1
3-1-1	Operating environment.....	3-1
3-2	Machine Installation.....	3-3
3-2-1	General	3-3
3-2-2	Alignment.....	3-8
3-3	Home Position Setting.....	3-13
3-4	Mounting and Removing the Safety Fence.....	3-14

3-5	Test Operation.....	3-15
3-5-1	Inspection during test operation	3-15
4	TROUBLESHOOTING.....	4-1
4-1	Fault Diagnosis.....	4-1

PART 5

APPENDIX

CONTENTS

1	SPECIFICATION LIST	1-1
2	RESTRICTIONS ON WORKPIECE SHAPE	2-1
2-1	Unserviceable Workpieces	2-1
2-2	Workpieces which cannot be Stacked after Machining.....	2-3
2-3	Chucks and Chuck Jaws	2-4
3	PNEUMATIC CIRCUIT	3-1
4	ALARM TABLES	4-1
4-1	PLC Alarms	4-1
5	M CODE TABLES	5-1
6	PARAMETER TABLES.....	6-1
6-1	(Keep Relay) Parameters	6-1
6-2	(Timer) Parameters	6-5
6-3	(Counter) Parameters.....	6-7
6-4	(Data) Parameter.....	6-9
6-4-1	PMC data table control.....	6-9
6-4-2	PMC parameters (data table)	6-9
7	BARRIER	7-1
7-1	Barrier Matrix.....	7-1
7-2	Setting the Barrier.....	7-1
8	MACHINE TRANSPORT	8-1

8-1	Unpacking the Machine with GL from the Wooden Crate.....	8-1
8-2	Transferring the Machine with GL in the Production Area	8-1