

CNC SYSTEMS

# **OSP5020M** **OSP500M-G**

---

---

**SPECIAL FUNCTION MANUAL**  
**(No.1) (4th Edition)**

TABLE OF CONTENTS

	<u>PAGE</u>
SECTION 1 PROGRAM INPUT/OUTPUT FUNCTIONS BY FLOPPY DISKS (OSP FORMAT) . .	1
1. Overview . . . . .	1
2. Floppy Disk Handling . . . . .	1
2-1. 3.5" Built-in Floppy Disk Drive . . . . .	1
2-2. 3.5" Portable Floppy Disk Drive . . . . .	2
2-3. 8" Portable Floppy Disk Drive . . . . .	4
3. Floppy Disk Input/output Function . . . . .	5
3-1. Outline of Operation . . . . .	5
3-2. Input/Output Relationship . . . . .	6
3-3. Types of Floppy Disks . . . . .	8
3-4. Sector Device . . . . .	9
4. Operations . . . . .	10
4-1. INIT: Initialize . . . . .	10
4-1-1. 3.5" Floppy Disk . . . . .	10
4-1-2. 8" Floppy Disk . . . . .	11
4-2. DEL: Delete . . . . .	13
4-3. RENAME: Name Change . . . . .	13
4-4. DIR: Directory . . . . .	13
4-5. FREE: Remaining Floppy Disk Area . . . . .	14
4-6. LIST: List of Files . . . . .	14
4-7. READ: Reading from Tape Reader . . . . .	14
4-8. Output of Files to the Tape Punch . . . . .	15
4-9. Verify . . . . .	16
4-10. Read from Bubble Memory . . . . .	16
4-11. Data Transmission to Bubble Memory . . . . .	17
4-12. Floppy Disk File Protection . . . . .	18
SECTION 2 PROGRAM INPUT/OUTPUT FUNCTIONS BY FLOPPY DISKS (IBM FORMAT) . .	19
1. Overview . . . . .	19

	<u>PAGE</u>
2. Floppy Disk Handling .....	20
2-1. Cautions On Handling Floppy Disks .....	20
2-2. Floppy Disk Operation .....	21
2-3. Sector Device Name .....	22
3. Floppy Disk Format .....	23
3-1. Applicable Floppy Disks .....	23
3-2. Floppy Disk Layout .....	24
3-3. Number of Files .....	24
4. Operations .....	25
4-1. Directory .....	25
4-2. Copy .....	27
4-3. Free (Remaining Floppy Disk Capacity) .....	32
4-4. Initializing .....	34
4-5. Deletion .....	37
4-6. Rename .....	39
4-7. Protect .....	41
5. Precautions on I/O Functions Using Floppy Disks .....	45
5-1. Parameter Setting .....	45
5-2. Parameter Setting for File Name .....	46
5-2-1. When an Extension is Used .....	46
5-2-2. When an Extension is Not Used .....	49
5-3. Parameter Setting for Number of Files .....	49
6. Error List .....	50
7. Examples .....	52
8. Floppy Disk Format (IBM Format) .....	56
8-1. Index Cylinder .....	58
8-2. Faulty Cylinder Information .....	62
8-3. Volume Label Information .....	63
8-4. File Directory .....	65
8-5. Floppy Disk Information Used in OSP Series .....	68

	<u>PAGE</u>
8-6. Examples .....	69
8-7. Data Writing Method .....	70
<b>SECTION 3 TAPE PUNCHER INTERFACE .....</b>	<b>87</b>
1. Function Overview .....	87
2. Tape Punch Panel .....	88
3. Parameter Setting .....	90
4. Operation Procedures .....	98
5. Tape Format .....	102
5-1. Input Format .....	102
5-2. Output Format .....	103
5-3. EIA SPECIAL CODES .....	105
6. Specifications .....	107
6-1. RS-232C Interface .....	107
7. External Device Connection .....	112
7-1. BTR (Behind Tape Reader) Method .....	112
7-2. DC Code Control .....	116
7-3. DC Code Control Type 2 .....	119
7-4. Slave Station Function .....	122
7-4-1. Connections of slave station OSP with an external equipment ...	122
7-4-2. Connections of slave station OSP with an external equipment (DC code control) .....	123
7-4-3. Two OSPs connected using the slave station function .....	125
8. Error Messages .....	126
9. Tape Punch Connection Examples .....	131
9-1. FACIT 4070 .....	132
9-2. FACIT N1000 .....	133
9-3. KYORITSUSHA - All Models (Tape Punch) .....	134
9-4. KYORITSUSHA - Accumulator D60 .....	135
9-5. CITIZEN - 7652 NC .....	136
9-6. CITIZEN - CRP-2500 .....	137
9-7. CASIO - 650NC, 750NC .....	138

	<u>PAGE</u>
9-8. JBM - PR30 .....	139
9-9. NEC DATA TERMINALS - NDT-9501 .....	140
9-10. TANAKA BUSINESS MACHINE - PT-30RS .....	141
9-11. TANAKA BUSINESS MACHINE - PT-30RP .....	142
9-12. FANUC - PPR .....	143
9-13. MIKUNI TOKUSHU KIKI - CF30, CF10 .....	144
9-14. TAKAHASI DENKI - HFD-35 .....	145
9-15. ANRITSU - DPT610A .....	146
9-16. ACC SYSTEM - PT-PR .....	147
 SECTION 4 ANIMATION FUNCTION .....	 148
1. General .....	148
1-1. Special Features .....	148
1.2. Main Functions .....	148
1-3. Screen Layout .....	151
1-4. Animation Screen, Explanation of Terminology .....	152
 2. Types of Animation .....	 158
2-1. Graphic Display Coordinate System .....	158
2-2. Explanation of Animation Related Functions .....	162
2-2-1. Trace/Animation .....	164
2-2-2. Tool Kind .....	165
2-2-3. Material .....	166
2-2-4. Graphic Erase .....	166
2-2-5. Data ON/OFF .....	167
2-2-6. High Draw .....	167
2-2-7. Graphic Data .....	167
2-2-8. Auto Scale .....	184
2-2-9. Area Change .....	185
2-2-10. Angle Change .....	188
2-2-11. Blank Definition Function (Blank Define) .....	190
2-2-12. Tool Shape Setting .....	222
2-3. Explanation of Animation Related NC Program .....	225
2-4. Rotary Axis, Parallel Axis, 5-Face Cutting .....	233
 3. Animation Display Method .....	 236

---

	<u>PAGE</u>
SECTION 5 TOOL PATH DISPLAY FUNCTION .....	238
1. Overview .....	238
1-1. Features .....	238
1-2. Major Functions .....	238
2. Setting of Display Data .....	240
2-1. Data Setting in The Graphic Data Mode .....	240
2-2. Graphic Data Setting Parameters .....	241
2-3. Data Setting in The Plane Change Mode .....	249
3. Tool Path Drawing .....	251
3-1. Operations .....	251
3-2. Contents of Display .....	251
3-3. Restart and Sequence Restart Operations .....	252
4. Parameters .....	253
SECTION 6 NC OPERATION MONITOR .....	254
1. Overview .....	254
2. NC Hour Meter .....	255
2-1. Contents of Display .....	255
2-2. Count Data and Set Data .....	256
2-3. Alarm .....	256
3. NC Work Counter .....	257
3-1. Content of Display .....	257
3-2. Count Data and Set Data .....	257
3-3. Alarm .....	258

	<u>PAGE</u>
SECTION 7 Hi2 - NC FUNCTION .....	259
1. Overview .....	259
2. High-speed NC Interpolation Function .....	259
3. Tolerance Control Function .....	260
3-1. Designating Tolerance Control Mode .....	260
3-2. Tolerance Control Parameters .....	261
3-3. Tolerance Control Mode Designation .....	264
3-4. Tolerance Control Guide .....	268
3-5. Alarm .....	269
SECTION 8 SYNCHRONIZED TAPPING FUNCTION .....	270
1. Overview .....	270
2. COMMANDS .....	270
3. TAPPING CYCLE OPERATIONS .....	273
4. Parameters .....	275
5. Precautions .....	276
6. Torque Monitoring Function During Synchronized Tapping .....	277