


MAKINO

ELECTRICAL MAINTENANCE MANUAL (MMMAX659201E)



MAX 65

TABLE OF CONTENTS

PAGE

CHAPTER 1 SAFETY PRECAUTION

| | |
|----------------------------|-----|
| 1.1 GENERAL..... | 1-1 |
| 1.2 SAFETY PRECAUTION..... | 1-1 |

CHAPTER 2 INTRODUCTION

| | |
|-----------------------|-----|
| 2.1 INTRODUCTION..... | 2-1 |
|-----------------------|-----|

CHAPTER 3 ELECTRICAL & CNC CONTROL SPECIFICATION

| | |
|---|-----|
| 3.1 INTRODUCTION TO ELECTRICAL CONTROL FUNCTIONS..... | 3-1 |
| 3.2 CNC UNIT..... | 3-3 |
| 3.3 ELECTRICAL SPECIFICATIONS..... | 3-4 |
| 3.4 CNC CONTROL SPECIFICATIONS..... | 3-6 |

CHAPTER 4 PREVENTIVE MAINTENANCE

| | |
|---|------|
| 4.1 INTRODUCTION..... | 4-1 |
| 4.2 CLEANING AND REPLACING CABINET AIR FILTER..... | 4-1 |
| 4.3 FUSE REPLACEMENT..... | 4-2 |
| 4.3.1 Replacing Fuses In Power Unit..... | 4-2 |
| 4.3.2 Replacing Fuses In The Power Supply Module For Drives..... | 4-3 |
| 4.3.3 Replacing Fuses In The Servo Amplifier Module..... | 4-4 |
| 4.3.4 Replacing Fuses In Spindle Amplifier Module..... | 4-5 |
| 4.3 BATTERIES REPLACEMENT..... | 4-6 |
| 4.4.1 Replacing Battery For Data Memory Backup..... | 4-6 |
| 4.4.2 Replacing Battery For Absolute Pulse Coders For Prof 3 Machines..... | 4-7 |
| 4.4.3 Replacing Batteries For Absolute Pulse Coder In α Series Servo Amplifier Module..... | 4-7 |
| 4.5 REPLACING POWER SUPPLY UNIT OR PRINTED CIRCUIT BOARD IN THE NC CARD CAGE..... | 4-8 |
| 4.6 REPLACING FAN MOTOR IN CNC UNIT..... | 4-10 |

CHAPTER 5 TROUBLESHOOTING AND DIAGNOSIS

| | |
|---|------|
| 5.1 INTRODUCTION..... | 5-1 |
| 5.2 THE PMC ADDRESS..... | 5-1 |
| 5.3 DI/DO ADDRESS AND BIT DISPLAY..... | 5-3 |
| 5.4 TROUBLESHOOTING THE CNC UNIT..... | 5-4 |
| 5.4.1 Power Cannot Be Turned On (Pro B)..... | 5-5 |
| 5.4.2 Power Cannot Be Turned On (Pro 3)..... | 5-6 |
| 5.4.3 Neither Manual Operation Nor Automatic Operation Can Be Executed..... | 5-7 |
| 5.4.4 Jog Operation Cannot Be Done..... | 5-9 |
| 5.4.5 Handle Operation Cannot Be Done..... | 5-10 |

TABLE OF CONTENTS

| | |
|---|------|
| 5.4.6 Automatic Operation Cannot Be Done..... | 5-11 |
| 5.4.7 Cycle Start LED Signal Has Turned Off..... | 5-16 |
| 5.4.8 Nothing Is Displayed On CRT..... | 5-17 |
| 5.5 TROUBLESHOOTING THE MACHINE..... | 5-18 |
| 5.6 ATC STANDBY CONDITIONS..... | 5-19 |
| 5.7 MOVING ATC TO STANDBY CONDITION..... | 5-19 |
| | |
| CHAPTER 6 CNC ALARMS | |
| 6.1 INTRODUCTION..... | 6-1 |
| 6.2 CNC ALARM DISPLAY..... | 6-2 |
| 6.3 CNC ALARM HISTORY DISPLAY..... | 6-2 |
| 6.4 CLEARING CNC ALARM HISTORY..... | 6-3 |
| 6.5 PROGRAM ERRORS (P/S ALARM)..... | 6-3 |
| 6.6 BACKGROUND EDIT ALARM..... | 6-11 |
| 6.7 ABSOLUTE PULSE CODER (APC) ALARM..... | 6-11 |
| 6.8 SERIAL PULSE CODER (SPC) ALARM..... | 6-11 |
| 6.9 SERVO ALARMS..... | 6-12 |
| 6.10 OVERTRAVEL ALARMS..... | 6-14 |
| 6.11 OVERHEAT ALARMS..... | 6-15 |
| 6.12 RIGID TAPPING ALARM..... | 6-15 |
| 6.13 SPINDLE ALARMS..... | 6-15 |
| 6.14 SYSTEM ALARMS..... | 6-16 |
| | |
| CHAPTER 7 PMC OPERATOR ALARM MESSAGES AND REMEDIES | |
| 7.1 INTRODUCTION..... | 7-1 |
| 7.2 PMC OPERATOR ALARMS AND REMEDY..... | 7-1 |
| | |
| CHAPTER 8 TROUBLESHOOTING SERVO SYSTEM | |
| 8.1 INTRODUCTION..... | 8-1 |
| 8.1.1 Servo Alarm List..... | 8-2 |
| 8.1.2 Spindle Alarm List..... | 8-2 |
| 8.2 POWER SUPPLY MODULE TROUBLESHOOTING..... | 8-4 |
| 8.2.1 Alarm Code 01..... | 8-4 |
| 8.2.2 Alarm Code 02..... | 8-4 |
| 8.2.3 Alarm Code 03..... | 8-4 |
| 8.2.4 Alarm Code 04..... | 8-5 |
| 8.2.5 Alarm Code 05..... | 8-5 |
| 8.2.6 Alarm Code 06..... | 8-5 |
| 8.2.7 Alarm Code 07..... | 8-5 |
| 8.3 SERVO AMPLIFIER MODULE TROUBLESHOOTING..... | 8-6 |
| 8.3.1 Abnormal Current Alarms (8,9,A,b,C,d,E)..... | 8-6 |
| 8.3.2 IPM Alarms (8,9,A,b,C,d,E)..... | 8-7 |
| 8.3.3 Control Power Supply Undervoltage Alarm (2 in the LED display)..... | 8-7 |

TABLE OF CONTENTS

| | | |
|--------|--|------|
| 8.3.4 | DC Link Undervoltage Alarm (5 in the LED display)..... | 8-7 |
| 8.3.5 | Fan Stopped Alarm (1 in the LED display)..... | 8-8 |
| 8.3.6 | Current Conversion Error Alarm | 8-8 |
| 8.3.7 | Overload Alarm..... | 8-8 |
| 8.3.8 | Feedback Disconnected Alarm..... | 8-8 |
| 8.3.9 | Motor Overheat Alarm..... | 8-9 |
| 8.3.10 | Invalid Servo Parameter Setting | 8-9 |
| 8.3.11 | Pulse Coder Error alarm..... | 8-9 |
| 8.3.12 | Rotation Speed Data Error Alarm..... | 8-9 |
| 8.3.13 | Pulse Coder Communication Error Alarm..... | 8-10 |
| 8.4 | SPINDLE AMPLIFIER MODULE TROUBLESHOOTING | 8-10 |
| 8.4.1 | Alarm A0, A1 | 8-10 |
| 8.4.2 | Alarm AL-01 | 8-11 |
| 8.4.3 | Alarm AL-02 | 8-11 |
| 8.4.4 | Alarm AL-03 | 8-12 |
| 8.4.5 | Alarm AL-07 | 8-12 |
| 8.4.6 | Alarm AL-09 | 8-12 |
| 8.4.7 | Alarm AL-12 | 8-13 |
| 8.4.8 | Alarm AL-13 | 8-13 |
| 8.4.9 | Alarm AL-15 | 8-13 |
| 8.4.10 | Alarm AL-16 | 8-14 |
| 8.4.11 | Alarm AL-19 | 8-14 |
| 8.4.12 | Alarm AL-20 | 8-14 |
| 8.4.13 | Alarm AL-24 | 8-15 |
| 8.4.14 | Alarm AL-25 | 8-15 |
| 8.4.15 | Alarm AL-26 | 8-15 |
| 8.4.16 | Alarm AL-27 | 8-16 |
| 8.4.17 | Alarm AL-28 | 8-17 |
| 8.4.18 | Alarm AL-29 | 8-17 |
| 8.4.19 | Alarm AL-31 | 8-17 |
| 8.4.20 | Alarm AL-32 | 8-18 |
| 8.4.21 | Alarm AL-34 | 8-18 |
| 8.4.22 | Alarm AL-35 | 8-18 |
| 8.4.23 | Alarm AL-36 | 8-19 |
| 8.4.24 | Alarm AL-37 | 8-19 |
| 8.4.25 | Alarm AL-39 | 8-19 |
| 8.4.26 | Alarm AL-40 | 8-20 |
| 8.4.27 | Alarm AL-41 | 8-20 |
| 8.4.28 | Alarm AL-42 | 8-21 |
| 8.4.29 | Alarm AL-43 | 8-21 |
| 8.4.30 | Alarm AL-44 | 8-22 |
| 8.4.31 | Alarm AL-46 | 8-22 |
| 8.4.32 | Alarm AL-47 | 8-23 |
| 8.4.33 | Alarm AL-49 | 8-23 |
| 8.4.34 | Alarm AL-50 | 8-23 |
| 8.4.35 | Alarm AL-52, AL-53 | 8-24 |
| 8.4.36 | Alarm AL-54 | 8-24 |
| 8.4.37 | Alarm AL-55 | 8-24 |

APPENDIX 1 DI/DO TABLE

APPENDIX 2 LIMIT SWITCHES & SOLENOID VALVES

APPENDIX 3 ELECTRICAL COMPONENT LAYOUT DIAGRAMS

APPENDIX 4 INTERCONNECTION DIAGRAM

APPENDIX 5 COMPONENT LIST

APPENDIX 6 CABLE LIST

APPENDIX 7 LOCATION OF PCB MODULE FOR PROF 3 NC UNIT

APPENDIX 8 LOCATION OF PCB MODULE FOR PRO B NC UNIT