

MAINTENANCE MANUAL

VERTICAL CENTER SMART 430A

VERTICAL CENTER SMART 530C

Manual No.: HD32MA0035E

NC Unit: MAZATROL SMART

Before using this machine and equipment, fully understand the contents of this manual to ensure proper operation. Should any questions arise, please ask the nearest Technical Center or Technology Center.

IMPORTANT NOTICE

1. Be sure to observe the safety precautions described in this manual and the contents of the safety plates on the machine and equipment. Failure may cause serious personal injury or material damage. Please replace any missing safety plates as soon as possible.
2. No modifications are to be performed that will affect operation safety. If such modifications are required, please contact the nearest Technical Center or Technology Center.
3. For the purpose of explaining the operation of the machine and equipment, some illustrations may not include safety features such as covers, doors, etc. Before operation, make sure all such items are in place.
4. This manual was considered complete and accurate at the time of publication, however, due to our desire to constantly improve the quality and specification of all our products, it is subject to change or modification. If you have any questions, please contact the nearest Technical Center or Technology Center.
5. Always keep this manual near the machinery for immediate use.
6. If a new manual is required, please order from the nearest Technical Center or Technology Center with the manual No. or the machine name, serial No. and manual name.

Issued by Manual Publication Section, Yamazaki Mazak Corporation, Japan

CONTENTS

1	INTRODUCTION	1-1
1-1	Outline of the Machine.....	1-1
1-1-1	Intended use of the machine	1-1
1-1-2	Operating positions.....	1-1
1-1-3	Features.....	1-1
1-2	List of Manuals to Be Used.....	1-2
1-3	Numbering System for Pages.....	1-2
1-4	Numbering System for Figures and Tables	1-2
2	SAFETY PRECAUTIONS	2-1
2-1	Rule	2-1
2-2	Basic Safety	2-1
2-3	Safety Considerations Relating to Operators including Clothing	2-3
2-4	Safety Considerations Relating to Machine Operation	2-3
2-5	Safety Considerations Relating to Holding Workpieces and Tooling	2-4
2-6	Safety Considerations Relating to Maintenance.....	2-5
2-7	Safety Considerations Relating to Workplace	2-6
2-8	Safety Considerations Relating to Chip Conveyor.....	2-7
2-9	Safety Considerations Relating to Safety Devices	2-7
2-10	Remarks on the Cutting Conditions Recommended by the NC.....	2-7
2-11	Safety Nameplates	2-7
2-12	Safety Devices	2-10

3	OUTLINE OF THE MACHINE	3-1
3-1	Configuration	3-1
3-2	Maintenance Cover	3-4
4	REGULAR INSPECTION	4-1
4-1	General.....	4-1
4-2	Table of Inspection and Maintenance Items	4-2
4-3	Daily Inspection and Maintenance.....	4-4
4-3-1	Inside the machine.....	4-4
4-3-2	Outside the machine.....	4-7
4-3-3	Checking oil levels	4-10
4-3-4	Checking the air pressure.....	4-10
4-3-5	Changing or replenishing oils	4-10
4-3-6	Around the machine.....	4-10
4-4	Weekly Inspection and Maintenance	4-11
4-4-1	Around the machine.....	4-11
4-5	Monthly Inspection and Maintenance	4-13
4-5-1	Around the machine.....	4-13
4-5-2	Maintenance of the line filter for through-spindle coolant (option)	4-13
4-6	Every Six-Month Inspection and Maintenance	4-17
4-6-1	Changing or replenishing oils	4-17
4-6-2	Around the machine.....	4-20
4-7	Every One- and Two-year Inspection and Maintenance.....	4-25
4-7-1	Changing or replenishing oils	4-25

4-7-2	Around the machine.....	4-26
4-8	Inspection and Maintenance before Stopping the Machine for a Long Time	4-30
4-9	Inspection and Maintenance before Starting the Operation after Stopping the Machine for a Long Time.....	4-31
5	MAINTENANCE OF MAJOR UNITS	5-1
5-1	Spindle	5-2
5-1-1	Troubleshooting	5-2
5-1-2	Construction of the spindlehead	5-3
5-1-3	Checking the collet/pusher	5-4
5-1-4	Checking the rotary joint.....	5-5
5-2	X-axis, Y-axis, Z-axis.....	5-6
5-2-1	Troubleshooting	5-6
5-2-2	Construction of the axis drive systems	5-6
5-2-3	Zero-point setting method.....	5-7
5-3	ATC Magazine.....	5-9
5-3-1	Troubleshooting	5-9
5-3-2	Construction of the ATC magazine	5-10
5-3-3	Cleaning the ATC magazine.....	5-11
5-4	Hydraulic System.....	5-12
5-4-1	Troubleshooting	5-12
5-4-2	Maintenance of the hydraulic unit	5-12
5-4-3	Hydraulic circuit diagram	5-14
5-5	Pneumatic System.....	5-15
5-5-1	Troubleshooting	5-15

5-5-2	Maintenance of the air unit	5-15
5-5-3	Pneumatic circuit diagram	5-16
5-6	Lubrication of Spindle and Linear Axis	5-18
5-6-1	Troubleshooting	5-18
5-6-2	Maintenance	5-18
5-6-3	Linear guide and ball screw lubrication (grease)	5-18
5-7	Spindle Cooling Unit	5-19
5-7-1	Troubleshooting	5-19
5-7-2	Construction of the spindle cooling unit	5-20
5-7-3	Spindle cooling circuit diagram	5-21
5-8	Coolant System	5-22
5-8-1	Troubleshooting	5-22
5-8-2	Construction of the coolant system	5-22
5-8-3	Maintenance of the chip conveyor	5-23
5-9	Covers	5-23
5-9-1	Troubleshooting	5-23
5-9-2	Machine covers	5-23
5-9-3	Maintenance of the X-axis way cover	5-24
5-9-4	Maintenance of the Y-axis way cover	5-25
5-9-5	Maintenance of the Z-axis way cover	5-27
5-9-6	Checking the wiper at the way cover	5-28
5-9-7	Changing the way cover wipers	5-32
5-9-8	Checking the pantograph at the way cover	5-33
5-9-9	Changing the reed switch	5-35

5-10	NC Unit and Electrical Control Cabinet.....	5-36
5-10-1	Troubleshooting	5-36
5-10-2	Resetting the thermal relay	5-36
5-10-3	Changing the proximity sensor	5-37
5-10-4	Replacing the battery for the spindle, X, Y, and Z axis amplifiers (For the amplifier installing the cell battery).....	5-38
5-10-5	Replacing the cell battery for the ATC magazine axis amplifier (For the amplifier installing the cell battery).....	5-40
5-10-6	Replacing the battery for the machine installing the central battery unit (For the machine installing the central battery unit)	5-41
6	INSTALLATION	6-1
6-1	Precautions on Installing the Machine	6-1
6-2	Preparing for Installation.....	6-1
6-2-1	Environmental requirements.....	6-1
6-2-2	External power source requirements	6-3
6-2-3	Air source requirements.....	6-7
6-2-4	Items to be confirmed when carrying the machine	6-7
6-2-5	Foundation work	6-9
6-3	Installation	6-10
6-3-1	Masses of machine units	6-10
6-3-2	Lifting	6-10
6-3-3	Unpacking, inspection and cleaning	6-12
6-3-4	Installation.....	6-13
6-4	Connecting to the Power and Air Sources.....	6-16
6-4-1	Connecting to the power source	6-16
6-4-2	Grounding	6-18

6-4-3	Connecting to the air source.....	6-20
6-5	Test Run.....	6-21
6-5-1	Checking the machine before starting test run	6-21
6-5-2	Electric inspection before switching the power ON.....	6-21
6-5-3	Checking the parameter settings	6-22
6-5-4	Checking the machine in manual operation.....	6-22
6-5-5	Breaking in operation.....	6-22
7	APPENDIX.....	7-1
7-1	List of Sensors, Limit Switches, and Oiling Points.....	7-1
7-1-1	List of sensors and limit switches	7-1
7-1-2	List of oiling points	7-2
7-2	List of Wearable Parts	7-3