

INSTRUCTION MANUAL

YAMAHA

MV-1100S

(FANUC 18iMB)

CONTENTS

PREFACE	I
BRIEF INTRODUCTION	II
1 SAFETY PRECAUTIONS	
1-1 SAFETY PRECAUTIONS	1-1
1-2 GENERAL SAFETY INSTRUCTIONS	1-2
2 MACHINE VIEWING	
2-1 BASIC INTRODUCTION	2-1
2-2 MACHINE OUTLINE DRAWING	2-2
3 SPECIFICATION OF MACHINE	
3-1 MACHINE SPECIFICATION	3-1
3-2 MAIN COMPONENTS SPECIFICATION	3-2
3-3 TOOL SPECIFICATION	3-5
3-4 CHIP CONVEYOR	3-6
4 PREPARATION AND TRANSPORTATION	
4-1 ENVIRONMENTAL REQUIREMENT	4-1
4-2 POWER SUPPLY	4-1
4-3 TRANSPORTATION	4-2
4-4 INSTALLATION AND POWER ON	4-7
4-5 LEVELING	4-13
4-6 SETTING GROUND	4-14
5 PNEUMATIC SYSTEM	
5-1 FEATURE OF OUTLINE	5-1
5-2 TECHNICAL DATA	5-2
5-3 THE PRESSURE SETTING METHOD OF F.R.L. UNIT	5-2
5-4 SKETCH OF PNEUMATIC SYSTEM	5-3
5-4 SKETCH OF PNEUMATIC SYSTEM (CE)	5-4
6 LUBRICATION SYSTEM	
6-1 TECHNICAL DATA	6-1
6-2 OUTLINE DIMENSION	6-1
6-3 FILL UP LUBRICATION OIL	6-2

6-4 THE LOOP SKETCH OF LUBRICATION SYSTEM	6-3
7 COOLANT SYSTEM	
7-1 OUTLINE DIMENSION OF COOLANT PUMP	7-1
7-2 TECHNICAL DATA	7-1
7-3 INSTALLATION AND PIPING NOTES	7-1
7-4 TROUBLESHOOTING	7-3
7-5 COMPONENTS OF PUMP	7-3
7-6 THE SKETCH OF COOLANT SYSTEM	7-4
8 HEAT EXCHANGER	
8-1 GENERAL CAUTIONS	8-1
8-2 TECHNICAL DATA	8-1
8-3 OUTLINE DRAWING	8-1
9 MAINTENANCE	
9-1 DAILY MAINTENANCE	9-1
9-2 WEEKLY MAINTENANCE	9-2
9-3 SEMIANNUAL MAINTENANCE	9-2
9-4 ANNUAL MAINTENANCE	9-3
9-5 MAINTENANCE OF ATC UNIT	9-3
9-6 ATC TROUBLESHOOTING	9-6
10 OPERATION	
10-1 CRT AND INPUT PANEL	10-1
10-2 OPERATION PANEL	10-2
10-3 DESCRIPTION OF FUNCTIONAL BUTTONS	10-3