


RAYCON EX1

Affordable Production inspection system for packaged products

- Hygienic, Industrial Design
- Focus on Usability:
 - Best in class user interface
 - Best cleanability and maintainability
 - Easiest handling & installation
- Easy decision!








RAYCON EX1

Performance features



The RAYCON EX1 product inspection system detects all contaminants that due to their density, chemical composition, or mechanical dimensions absorb X-rays better than the surrounding product. This applies to metal, glass, ceramic, and stone contaminants in food materials. The RAYCON system also detects some types of plastics (e.g. PVC, rubber) as well as other product defects (e.g. trapped air, filling level).




Detectability of different materials depending on their density

The RAYCON EX1 product inspection system is characterised by the following performance features:

- Inspection area: 220/120 (W x H)
- Throughput: ~220 pcs./min. (product specific)
- \blacksquare Detection capability starting from Ø 0,6 mm
- 60W Low-Energy X-Ray generator
- Highest operator safety due to low X-Ray emission < 0.5μSv/h
- Short over-all length of only 800mm (1200mm with Optional integrated reject)
- Modular and stable frame design allows easy transportation and safe installation
- Ambient temperatures from 0°C to +40°C
- IP 54 protection class
- Reject system: Signal only (Air Blast or Pusher available on Integrated reject version).

Function



The system comprises of the following main components:

A X-ray tube

This is where X-rays are electrically generated. The X-rays are emitted from the tube through a narrow slot and as a fan-shaped beam pass through the product to be inspected from back to front.

B X-ray beam

C Transport system

A PE flat belt (self guiding) uniformly transports the product to be inspected through the X-ray beam. This makes it possible to scan the product line-by-line.

Detector unit

The linear detector that is installed above the inspection aperture converts the arriving X-rays into an electrical signal from which a digital X-ray image is created.

Industry-type PC

The PC is used to evaluate the images and to accurately control the reject systems.

Software advantages

Evaluation software

The product inspection system is equipped with a high-performance industrial PC with real-time operating system and sophisticated visualisation software.

A 10" LCD touch screen monitor is used for the user interface.

X-ray images are evaluated by a product specific visualization software. Contaminated or defective products are detected and rejected.

User Interface

Drag & Drop menus

The operator receives a visual feedback instantly

→ Time saving

Menu guide

The operator is guided by the software through necessary steps of product setup or troubleshooting

→ Time saving

Easiest and fastest product setup

Autolearn with 5 product samples only

→ Startup in less than 2 minutes

Retrain for automatic sensitivity adjustment.

Software increases/decreases sensitivity automatically based on the Operator marking the x-ray image on the touch screen.

→ Saves time consuming adjustments


No special expertize or knowledge required to operate.

RAYCON EX1 design overview

Design & Hygiene:

Saving time for maintenance & cleaning due to:

- Inclined surfaces, water flows off easily
- Tool-less accessibility
- Tool-less removal of curtains in less than 1 minute
- Tool-less conveyor belt removal in less than 2 minutes





Example of RAYCON EX1 with Integrated reject.

Important information:

X-radiation is classified as ionising radiation. However, X-radiation is not radioactive radiation! In accordance with EU directive 1999/2/EC, Sesotec X-ray systems due to the minimum radiation energy can be used for the contaminant inspection of food materials even with organic products. The RAYCON product inspection system is subject to the German X-ray ordinance and requires certification. Please observe any country-specific regulations!

For detailed information please request our technical data sheet.

Sesotec Inc.

1234 Hardt Circle Bartlett, IL 60103 USA

Tel.: +1 224-208-1900 Fax: +1 224-208-1909 info@sesotec.us www.sesotec.us

Sesotec GmbH

Regener Straße 130 D-94513 Schönberg Germany Tel. +49 8554 308-0 Fax +49 8554 2606 info@sesotec.com www.sesotec.com

Operating Companies:

Sesotec ASM S.r.l.

Bologna Italy info.asm@sesotec.com www.sortingasm.com



Sesotec Inc.

Bartlett USA info@sesotec.us www.sesotec.us



Sesotec Canada Ltd.

Cambridge Canada info@sesotec.us www.sesotec.ca



Sesotec Pte. Ltd.

Singapore info@sesotec.com.sg www.sesotec.com.sg



Sesotec Pvt. Ltd.

Pune India info.india@sesotec.com www.sesotec.com



Sesotec Shanghai Co. Ltd.

Shanghai China enquiry@sesotec.com.cn www.sesotec.com.cn



Sesotec Thailand Ltd.

Bangkok Thailand info@sesotec.com www.sesotec.com

... and more than 40 agencies worldwide

Made in Germany

Sesotec system world



Detecting and separating contaminants:

Removing contaminants:

- metals
- plastics
- glass
- ceramics, porcelain, stones
- and many others

Removing from (good material):

- bulk materials
- liquids and pastes
- individually packaged product
- packed and loose items

Product types:

- end-products (food, textiles, plastics etc)
- industrial raw materials
- recycled materials

can be integrated into all types of conveyor systems

Detecting and separating sub-standard products:

Qualitative defects:

- incorrect colour
- agglomerations
- breakages
- air inclusions in packs
- incorrect positioning / distribution

Quantitative defects:

- of items in package)

Product types:

- end-products (food, textiles,
- industrial raw materials
- recycling materials

- incorrect weight
- count errors (incorrect number

- plastics etc)

can be integrated into all types of conveyor systems

Types of material: glass plastics

mixed materials into

single fractions:

- metals

Sorting

and many others

Delivery flows:

- bulk materials
- individually packaged product

can be integrated into:

- conveying systems
- bulk material flows

For further information or to discuss your particular application contact one of our specialists.

www.sesotec.us

