

# **RotoPol-21**

# **RotoPol-22**

# **RotoPol-25**

Instruction Manual

Manual No.: 15157001

Date of Release: 06.04.1998

## Table of Contents

Page

User's Guide .....	1
Reference Guide .....	21

---

Always state *Serial No* and *Voltage/frequency* if you have technical questions or when ordering spare parts. You will find the *Serial No.* and *Voltage* on the front cover of this manual or on an attached label below. If in doubt consult the rating plate of the machine itself. We may also need the *Date* and *Article No* of the manual. This information is found on the front cover.

The following restrictions should be observed, as violation of the restrictions may cause cancellation of Struers legal obligations:

**Instruction Manuals:** Struers Instruction Manual may only be used in connection with Struers equipment covered by the Instruction Manual.

**Service Manuals:** Struers Service Manual may only be used by a trained technician authorized by Struers. The Service Manual may only be used in connection with Struers equipment covered by the Service Manual.

Struers assumes no responsibility for errors in the manual text/illustrations. The information in this manual is subject to changes without notice. The manual may mention accessories or parts not included in the present version of the equipment.

The contents of this manual is the property of Struers. Reproduction of any part of this manual without the written permission of Struers is not allowed.

All rights reserved. © Struers 1996.

**Struers A/S**  
Valhøjs Allé 176  
DK-2610 Rødovre/Copenhagen  
Denmark  
Telephone +45 36 70 35 00  
Telefax +45 38 27 27 01

---

# User's Guide

## Table of Contents

Page

### 1. Getting Started

Checking contents of packing .....	3
- <i>RotoPol-21/22/25</i> .....	3
- <i>Recirculation cooling unit (TRECI)</i> .....	4
- <i>Recirculation cooling unit connector (ROPRE)</i> .....	4
Getting acquainted with RotoPol-21/22/25 .....	5
Unpacking RotoPol-21/22/25 .....	5
Placing RotoPol-21/22/25 .....	5
Supplying power .....	6
- <i>RotoPol-21 and -22</i> .....	6
- <i>RotoPol-25</i> .....	6
- <i>Direction of turntable</i> .....	6
Supplying water .....	6
- <i>Connection to water mains</i> .....	6
- <i>Connection to water outlet</i> .....	7
Software Settings .....	7
Setting the language	
- <i>Language Setting for RotoPol-21 and -25</i> .....	8
- <i>Language Setting for RotoPol-22</i> .....	9

## **2. Basic Operations**

Using the controls .....	10
Front panel controls	
- <i>The front panel of RotoPol-21</i> .....	10
- <i>The front panel of RotoPol-22</i> .....	12
- <i>The front panel of RotoPol-25</i> .....	14
- <i>General use of keys</i> .....	16
Reading the display .....	16
- <i>With a RotoCom Memory Unit</i> .....	19
Routine operations .....	16
- <i>Mounting a disc</i> .....	16
- <i>Starting the disc</i> .....	16
- <i>Stopping the disc</i> .....	16
User Select on RotoPol-21 and -22	
- <i>Selecting water and speed</i> .....	17
- <i>Setting to User Select</i> .....	17
- <i>Setting to GRINDING</i> .....	17
- <i>Setting to POLISHING</i> .....	17
User Select on RotoPol-25	
- <i>Selecting water</i> .....	18
- <i>Setting to User Select</i> .....	18
- <i>Setting to GRINDING</i> .....	18
- <i>Setting to POLISHING</i> .....	18

# Reference Guide

Table of Contents	Page
<b>1. Advanced Operations</b>	
Selection of disc .....	22
Mounting of specimen mover (optional) .....	22
Mounting of Multidoser (optional) .....	22
RotoCom memory unit (optional) .....	22
Setting the communication .....	23
Configuration of RotoPol-22 .....	24
- <i>Setting AUTO MODE when RotoForce-3 or -4 is mounted</i> ...	24
- <i>Setting 2-DISC SYSTEM when RotoForce-1 is mounted</i> ...	24
Struers Metalog Guide™ .....	25
Oxide Polishing .....	26
Overview of menu screens in the setup menu	
- <i>RotoPol-21 and -25 setup menus</i> .....	27
- <i>RotoPol-25 setup menus</i> .....	28
<b>2. Accessories and Connected Equipment</b> .....	29
<b>3. Trouble-shooting</b> .....	30
<b>4. Maintenance</b>	
Daily service .....	31
Weekly service .....	31
Replacing the cooling water .....	31
Checking the recirculating cooling unit .....	31
<b>5. Technical Data</b>	
Technical Data .....	32
Spare parts and diagrams .....	34