

OPERATING MANUAL

for

QUICK TURN 8N CHUCKER & UNIVERSAL

MAZATROL T32 B

PUBLICATION NO.: M147SA0033E

[PRECAUTIONS]

-  Before operating this machine, please read this manual with care and fully understand the contents of the manual so that the machine can exert its performance safely.
-  Although the contents of this manual are closely checked for perfection, if there is any ambivalent point, incorrect description, or omission, contact us, please.
-  In order to explain the details, all the illustrations contained in this manual do not necessarily show the covers, doors, safety guards, or shields. Therefore, be sure to restore all the specified covers, shields, etc., and observe the contents of the manual when operating this machine. If this precaution is ignored, a serious accident may incur, resulting in damage to the important units of the machine and other accessories.
-  This manual is subject to modifications and changes as required for the improvement in, and the change in the specification of, the machine and the CNC equipment, as well as for usability of the manual itself. The modifications and changes are indicated by updating the manual numbers in a revised version.
-  When your manual is damaged or lost, and a new material is needed, inform us of the "manual number."
 - If the manual number is not identified, inform us of the following:
 1. Name of the machine
 2. Number of the machine
 3. Name of the manual
-  Contact the Technical Center (TC) or the Service Center (SC) of Yamazaki Mazak for operations of this machine and replacement of the manual.

Issue of the manual: Manual Publication Team of Engineering Generalization Section,
Yamazaki Mazak Co., Ltd.

06.1992

CONTENTS

	Page
1. INTRODUCTION	
1-1 Preface	1
1-2 Caution as to Safe Operation	2
1-3 Transportation/Installation	5
1-3-1 Standard accessories of machine	5
1-3-2 Articles to be prepared by user prior to delivery	5
1-3-2-1 Environment (Machine side)	5
1-3-2-2 Environmental conditions (NC side)	5
1-3-2-3 Required air source	6
1-3-2-4 Intakes	6
1-4 Installing Method	6
1-4-1 Installation procedure	6
1-4-2 Lifting method using ropes	6
1-5 External View, Width, Height, and Length when Installed	7
1-6 Installation Method	7
1-7 Final Centering Adjustment	8
1-8 Installation and Maintenance of Intermachine Connection	9
2. SPECIFICATION	9
2-1 Development of Specification	9
2-1-1 Specification development diagram	9
2-1-2 Special accessories for FA	9
2-1-3 Specification variation chart	10
2-2 Specification of Standard Machine	11
2-3 Spindle Speed - Power Diagram	12
3. STRUCTURE	15
3-1 Name of Each Part	15
3-2 Mechanism of Each Part	15
3-2-1 Headstock	15
3-2-2 Chuck	15
3-2-3 X-axis, Z-axis	15
3-2-4 TOOL EYE	16
3-2-5 Turret	17
3-2-6 Tailstock	18
3-2-7 Hydraulic circuit	19
3-2-8 Lubrication circuit	21
3-2-9 Air circuit	21
3-3 Main Purchase Article List	21
4. OPERATION PANEL & OPERATION	22
4-1 OPERATION Panel Drawing	22
4-2 Operation Overall Flow Chart	23
4-3 Preliminary Operation	24
4-3-1 Operation starting procedure	24
4-3-2 Emergency stop method	24
4-3-3 Operation for work stop	25
4-4 Manual Operation	25
4-4-1 Zero-point return operation	25
4-4-2 Feeding operation	26
4-4-3 Spindle operation	28
4-4-4 Turret swinging operation	28
4-4-5 Tailstock operation	29
4-4-6 Foot switch operation for chuck	29
4-4-7 Function of each manual switch	29
4-4-8 Adjusting spots for operation	34
4-4-9 Inputting operation to TOOL SET display	35
4-4-10 Inputting operation to SET UP display	36
4-5 Automatic Operation	37

	Page
5. INSPECTION & MAINTENANCE	39
5-1 Daily Inspection	39
5-2 Periodic Inspection	40
5-3 Oil & Cutting Fluid	41
5-3-1 Oiling spot	41
5-3-2 Maintenance of hydraulic unit	41
5-3-3 Maintenance of lubricating unit	42
5-3-4 Greasing spots	42
5-3-5 Maintenance of cutting fluid unit	43
5-4 Adjustment and Maintenance of Each Part	43
5-4-1 V-belt and timing belt	43
5-4-2 Headstock	44
5-4-3 Chuck	45
5-4-4 Machine zero-point	45
5-4-5 Backlash	48
5-4-6 TOOL EYE	48
5-4-7 Turret	49
5-4-8 Tailstock	49
5-4-9 Maintenance of other regions of machine	49
5-4-10 Maintenance of electric system	50
5-5 Troubleshooting	50
5-5-1 Inspection items in case of trouble occurrence	50
5-5-2 I/O check on the DIAGNOSIS display	51
6. TOOLING	52
6-1 Octagonal Turret	52
6-1-1 Tooling system	52
6-1-2 Program diagram	54
6-1-3 Interference diagram	56
6-2 Dodecagonal Turret	63
6-2-1 Tooling system	63
6-2-2 Program diagram	65
6-2-3 Interference diagram	67
6-3 Tooling of QT-8N LIST of unit code NO.	71
6-4 Tool holder	73
6-4-1 Octagonal drum turret	73
6-4-2 Dodecagonal drum turret	87
7. CODE LIST	95
8. CHUCK	98
8-1 Standard Chuck Specifications	98
8-2 Specifications of Chuck for FA (Factory Automation)	100
8-3 Specifications of Chuck for FA (Hollow Chuck)	102
8-4 Spindle Noze	106
8-5 Dimensional Drawing of Parts Catcher	107
9. TOOL EYE	109