

Standard Electrical Formulas Used for Power Consumption Calculations

TO DETERMINE	SINGLE-PHASE	THREE-PHASE	DIRECT CURRENT
Amperes (when HP is known)	<u>HP x 746</u>	<u>HP x 746</u>	<u>HP x 746</u>
	E x %EFF x PF	1.73 x E x %EFF x PF	E x %EFF
Amperes (when kW is known)	<u>KW x 1000</u>	<u>KW x 1000</u>	<u>KW x 1000</u>
	E x PF	1.73 x E x PF	E
Amperes (when KVA is known)	<u>KVA x 1000</u> E	<u>KVA x 1000</u> 1.73 x E	Not Applicable
Horsepower	<u>I x E x %EFF x PF</u>	<u>l x E x 1.732 x %EFF x PF</u>	<u>I x E x %EFF</u>
	746	746	746
Kilovolt/ Amperes	<u>I x E</u> 1000	<u>I x E x 1.73</u> 1000	Not Applicable
Kilowatts	<u>I x E x PF</u>	<u>I x E x 1.73 x PF</u>	<u>l x E</u>
	1000	1000	1000

I = amperes
E = volts
KW = Kilowatts
KVA = kilovolt/amperes
HP = horsepower
% Eff. = percent efficiency
PF = power factor